Hybrid Inverter

Installation and Operation Manual



www.aforenergy.com



Version: HH1004-03

Afore New Energy Technology (Shanghai) Co., Ltd.

Ad Building 7, No.333 Wanfang Rd, Minhang District, Shanghai, China. 201112



Afore New Energy Technology (Shanghai) Co., Ltd.

Contents



Contents

1. About This Manual	1 1 1
2. Safety & Symbols	1
2.1 Safety Precautions	1
2.2 Explanations of Symbols	2
3. Introduction	3
3.1 Basic Instruction	3
3.2 Operation Modes	3
3.2.1 Self-Use	3
3.2.2 Time of Use	4
3.2.3 Selling First	6
3.2.4 Back-Up	6
4. Installation	7
4.1 Pre-installation	7
4.1.1 Unpacking & Package List	7
4.1.2 Product Overview	8
4.1.3 Mounting Location	9
4.2 Mounting	11
4.3 Electrical Connection	12
4.3.1 Communication	13
4.3.1.1 Adaptation Switch	13
4.3.1.2 BAT/Meter/CT	14
4.3.1.3 Adaptation Switch	18
4.3.1.4 WIFI/GPRS/LAN	19
4.3.1.5 BAT-CAN/NTC	19
4.3.1.6 DRM (Demand Response Mode)	21
4.3.2 PV Connection	21
4.3.3 Battery Connection	22
4.3.4 AC Connection	23
4.2.5 Forth Connection	





5. Operation	27
F. 1 Central Danel	 27
F.O. Manus Overminus	 28
5.3 Inverter Setting	 28
5.3.1 Time & Date	29
5.3.2 Safety	29
5.3.3 Lithium Battery	30
5.3.4 PV Mode	30
5.3.5 Lead Acid	30
5.3.6 Energy Management System (EMS Param)	31
5.3.7 Timing of Use	32
5.3.8 AC Charging	32
5.3.9 Forced Charging	33
5.3.10 Forced Discharging	33
5.3.11 Protection Parameters	34
5.3.12 Multi-machine in Parallel	34
5.3.13 Diesel Generator Setting	35
6. Power ON/OFF	35
6.1 Power ON	
6.2 Power OFF	
6.3 Restart	
	50
7. Maintenance & Trouble Shooting	36
	36
- 0 - 11 OL 11	36
8. Specifications	47





1.About This Manual

1.1 Scope of Validity

This manual mainly describes the product information, guidelines for installation, operation, maintenance and troubleshooting. And this manual applies to Afore Single Phase Hybrid Inverter.

AF3K-DH AF3.6K-DH AF4K-DH AF4.6K-DH AF5.5K-DH AF6K-DH AF7.6K-DH AF8.6K-DH AF8.6K-DH AF9.6K-DH

Please keep this manual available all the time in case of any emergency.

1.2 Target Group

This manual is for qualified personnel. The tasks described in this manual must only be performed by qualified personnel.

2. Safety & Symbols

2.1 Safety Precautions

- 1. All work on the inverter must be carried out by qualified electricians.
- 2. The PV panels and inverter must be connected to the ground.
- 3. Do not touch the inverter cover until 5 minutes after disconnecting both DC and AC power supply.
- 4. Do not touch the inverter enclosure when operating, keep away from materials that may be affected by high temperatures.
- 5. Please ensure that the used device and any relevant accessories are disposed of in accordance with applicable regulations.
- Afore inverter should be placed upwards and handled with care in delivery. Pay attention to waterproof. Do not expose the inverter directly to water, rain, snow or spray.
- 7. Alternative uses, modifications to the inverter not recommended. The warranty can become void if the inverter was tampered with or if the installation is not in accordance with the relevant installation instructions



2.2 Explanations of Symbols

Afore inverter strictly comply with relevant safety standards. Please read and follow all the instructions and cautions during installation, operation and maintenance.



Danger of electric shock

The inverter contains fatal DC and AC power. All work on the inverter must be carried out by qualified personnel only.



Beware of hot surface

The inverter's housing may reach uncomfortably hot 60°C (140°F) under high power operation. Do not touch the inverter enclosure when operation.



Residual power discharge

Do not open the inverter cover until 5 minutes after disconnection both DC and AC power supply.



Important notes

Read all instructions carefully. Failure to follow these instructions, warnings and precautions may lead to device malfunction or damage.



Do not dispose of this device with the normal domestic waste.



Refer to manual before service.






3. Introduction

3.1 Basic Instruction


The Afore AF-DH series hybrid inverters are designed to increase energy independence for homeowners. Energy management is based on time-of-use and demand charge rate structures, significantly reduce the amount of energy purchased from the public grid and optimize self-consumption.



3.2 Operation Modes


3.2.1 Self-use

The Self-Use mode is for the regions with low feed-in tariff and high electricity prices. The energy produced by the PV system is used to optimize self-consumption needs. The excess energy is used to recharge the batteries, any remaining excess is then exported to the grid.



Energy flow: $PV \rightarrow Load \rightarrow Battery \rightarrow Grid$





When select 0 W under P_Feed menu, the inverter will export zero energy to the grid.


When select xx W under P_Feed menu, the inverter will export customized energy to the grid.

3.2.2 Time of Use

The Time of Use mode is designed to reward customers who do their part to reduce demand on the electric grid, particularly during peak usage periods. Use most of your electricity from PV energy and during off-peak time periods, and you could significantly lower your monthly bill.

A. Charge Setting

PV Charge Mode




4 periods of time charge setting.

Energy flow:

 $\mathsf{PV} \to \mathsf{Battery} \to \mathsf{Load} \to \mathsf{Grid}$

AC Charge Mode



4 periods of time charge setting.

Energy flow: PV and Grid → Battery → Load








Note

After select AC charge, the AC will also charge the battery when the PV is low or no PV.

B. Forced discharge


4 periods of time discharge setting



Battery and PV \rightarrow Load \rightarrow Grid

C. Forbidden Discharge

4 periods of time discharge setting, the battery will be charged firstly.








3.2.3 Selling First


The Selling First mode is suitable for the regions with high feed-in tariff.



Energy flow: $PV \rightarrow Load \rightarrow Grid \rightarrow Battery$

3.2.4 Back-Up

When the grid fails, the system will automatically switch to Back-Up mode. The back-up loads can be supplied by both PV and battery energy.



Energy flow: $PV \rightarrow Battery \rightarrow Load \rightarrow Grid$





4. Installation

4.1 Pre-installation


4.1.1 Unpacking & Package List

Unpacking

On receiving the inverter, please check to make sure the packing and all components are not missing or damaged. Please contact your dealer directly for supports if there is any damage or missing components.

Package List

Open the package, please check the packing list shown as below.





No.	Qty	Items	No.	Qty	Items
1	1	Hybrid Inverter	9	1	Security Screw
2	1	Wall Mounting Bracket	10	3	Expansion Tube
3	1	Quick Installation Instructions	11	3	Backet Screw
4	1	Certificate of Inspection	12	18	Battery Terminals
5	1	Warranty Card	13	4	Earth Terminals
6	1	Monitor Quick Installtion	14	1	Monitor Module
7	1	Smart Meter (Opitional)	15	10	Power Connectors
8	2	СТ	16	6	Communication Connectors

4.1.2 Product Overview










Inverter Terminals



No.	Items	No.	Items
1	Emergency Stop	6	Grid Port
2	DC Switch	7	BACK UP
3	Battery Port	8	Communication Port
4	Wifi Port	9	Waterproof Ventilating Valve
5	PV Port	10	Grounding Screw

4.1.3 Mounting Location


The inverters are designed for indoor and outdoor installation (IP65), to increase the safety, performance and lifespan of the inverter, please select the mounting location carefully based on the following rules:

- The inverter should be installed on a solid surface, far from flammable or corrosion materials, where is suitable for inverter's weight and dimensions.
- The ambient temperature should be within -25 $\rm C\sim60~C$ (between -13 $^{\circ}F$ and 140 $^{\circ}F$).
- The installation of inverter should be protected under shelter. Do not expose the inverter to direct sunlight, water, rain, snow, spray lightning, etc.






• The inverter should be installed vertically on the wall, or lean back on plane with a limited tilted angle. Please refer to below picture.




• Leave the enough space around inverter, easy for accessing to the inverter, connection points and maintenance.






4.2 Mounting







4.3 Electrical Connection









4.3.1 Communication

Communication terminals and configured switches on the bottom of the inverter:



No.	Item	Switch
1	Communication terminal	Adaptation switch
2	Communication terminal	BAT485 and Meter
3	Communication terminal	NTC and BAT CAN
4	Communication terminal	RS485
5	Communication terminal	CT1 and CT2
6	Communication terminal	DRM
7	Communication terminal	Dry Connector

4.3.1.1 Adaptation Switch



NO.	S1 Adaptation Switch	Remarks
1	Emergency switch, default is off	OFF
2	CAN-BAT	ON
3	CT485	ON
4	BAT485	ON
5	RS485_2	ON
6	RS485-WIFI	ON



4.3.1.2 BAT/Meter/CT


Meter and a current sensor (CT for short below) are used to detect current power direction of thelocal load and the grid. The output control function of the inverters will be activated basedonthe detected data.




Note:

Set Make sure AC cable is totally isolated from AC power before connecting Smart Meter & CT.

One meter and 2pcs CT used for one hybrid inverter.











Step 2 Connect the Meter to the inverter





D:--



PIN	BAT & Meter 485
1	Meter 485A
2	Meter 485B
3	BAT 485A
4	BAT 485B

Connect the meter with the inverter

With negative value, the hybrid inverters is feeding power to the grid.

With positive value, the load is consuming the power from grid.


With below figures and "Imp.", the system is importing active energy.

With below figures and "Exp.", the system is exporting active energy.







Step 1 Install the CT



Step 2 Connect the CT to the inverter



The CT communication port






Step 3	Pin	CT-AC/Meter
րրրը	1	CT_U
	2	CT_N
0000	3	CT_W
PIN 1234	4	CT_N

4.3.1.3 Adaptation Switch

RS485-3 connector is for Multi inverter parallel communication connection. Please check with local distributor or AIMS Power for more information.








4.3.1.4 WIFI/GPRS/LAN

The WiFi/GPRS/LAN module could transmit data to cloud server, and display data on PC(personal computer), tablet and smart-phone.

Install the WIFI / Ethernet / GPRS / RS485 Communication

Turn on the AC power supply and the AC breaker, until the LED indicator on the WiFi/GPRS/LAN module flashing.




Setting the communication module, router, account registration, etc. For more information, please check the WIFI/GPRS/LAN connection manual via www.aforenergy.com.

4.3.1.5 BAT-CAN/NTC


NTC is a temperature sensor, which is installed on the surface of the lead-acid battery byconnecting the lead wire to the TEP terminal of the inverter. If inverter is connected with lithiumbattery, it supports communication CAN & RS485, communication connecting steps please refer to Chapter 4.4.2. Connecting steps of the lead-acid battery or lithium battery to the inverter please refer to Chapter 4.3.2.







Step 2





PIN 1234

Pin	BAT NTC & CAN
1	TEP T
2	TEP G
3	CAN H
4	CAN L






Note:

NTC (temperature sensor) : Lead Acid

CAN: Lithium


4.3.1.6 DRM (Demand Response Mode)



4.3.2 PV Connection


The AF-DH series hybrid inverters up to three MPPT channels, can be connected with threestrings of PV panels. Please make sure below requirements are followed before connecting PVpanels and strings to the inverter:

- Disconnect all the PV (DC) switches before wiring
- · The open-circuit voltage and short-circuit current of PV string should not exceed thereasonable range of the inverters
- \cdot The isolation resistance between PV string and ground should exceed 300 $k\Omega$
- polarity of PV strings are correct
- · Use the DC plugs in the accessory box









- · PV input wire ≥ 8AWG, stripping length 11±0.5mm, the stripped PV input wire should betightly crimped into the connectors.
- · Pass the PV input wire with crimped terminals through the waterproof connector andfollow the system connection diagram as shown above, insert the black wire PV1-, PV2-, PV3- and the red wire PV1+, PV2+, PV3+ into the terminals on the PCB, and tighten thescrews.



Warning:

The fatal high voltage may on the PV string, please comply with electric safety in Chapter 2.0 when connecting.

Please make sure the right polarity of PV strings, otherwise inverter could be damaged.

4.3.3 Battery Connection

AF-DH series hybrid inverters are compatible with lithium battery. For lead acid battery or batteries with other brands, please confirm with local distributor or Afore for technical support.



Note

Set battery type and manufacturer, please refer to Chapter 5.3.




Note


BMS (Battery Management System) communication is needed between inverter and battery.











4.3.4 AC Connection

There are three AC terminals marking with "GRID", "EPS" and "GEN".

Before connecting, a separate AC breaker between individual inverter and AC input power is necessary. This will ensure the inverter be securely disconnected during maintenance and fullyprotected from current of AC input. An extra AC breaker is needed for On-Grid connection to be isolated from grid when necessary. Below are requirements for the On-Grid AC-breaker.

Inverter Model	AC breaker specification
AF3.0K-DH~AF7.6K-DH	63A/240V/208V AC breaker
AF8.0K-DH~AF9.6K-DH	100A/240V/208V AC breaker



Note:

Qualified electrician will be required for the wiring.


Model	Wire Size	Cable (mm²)	Torque value	
6/9.6kW	8-10AWG	6-8	1.2Nm	




Please follow steps for AC connection

- · Connect DC protector or breaker first before connecting.
- \cdot Remove insulation sleeve 11mm (0.5 inch) length, unscrew the bolts, insert the AC input wires according to polarities indicated on the terminal block and tighten the terminal screws.

Grid Connection










Note:

Make sure that AC power source is disconnected before connection.







EPS Connection








EPS Connection







· Then, insert stripped AC output wires into the terminal block according to polarities indicated and tighten the terminal. Corresponding N wires and PE wires to the AC terminal should be inserted as well.




Note:

Make sure the wires are securely connected.

4.3.5 Earth Connection

A second protective earth (PE) terminal should be connected to the inverter. This prevents electric shock if the original protective PE wire fails.



Fix the grounding screw to the grounding connection of the machine housing.




Note:

EMake sure the earth cables on the inverter and solar panel frame are separately.



5. Operation

5.1 Control Panel



No.	Items	No.	Items
1	LCD Display	5	UP Touch Button
2	POWER LED Indicator	6	DOWN Touch Button
3	GRID LED Indicator	7	BACK Touch Button
4	FAULT LED Indicator	8	ENTER Touch Button

Note:
Hold UP/DOWN button can be rolling quickly.

Sign	Power	Color	Explanation	
POWER	ON	Green	The inverter is stand-by	
	OFF		The inverter is power off	
GRID	ON	Green	Green The inverter is feeding power	
	OFF		The inverter is not feeding power	
FAULT	ON	Red	Fault occurred	
	OFF		No fault	



5.2 Menu Overview

AF-DH hybrid inverter has a LCD for clearly operating, and menu of the LCD can be presented as following: PV Info Bat Info Inv Info Run Info Grid Info Safty Load Info Model **EPS Info** Prated Err Record Tem Info Vrated Run Record Irated Sys Info RunTimeDay PV Mode RunTimeAll Display Menu WIFI SN **Bat Param** Version Running Param **EMS Param** Meter Param Protection Param P Mode Q Mode Grid Ctrl Diese1Gen Param Start / Stop Lang System Param Safty Date & Time Wifi Com Param Parallel

5.3 Inverter Setting


Sys Cmd

The setting is for AF-DH Hybrid inverter. Any doubts, please contact distributor for more details.






5.3.1 Time & Date




5.3.2 Safety







5.3.3 Lithium Battery



5.3.4 PV Mode



5.3.5 Lead Acid





Brand	COMM	OM/S	ACRED
Capacity		0-	-1000Ah
BatResC	omp	0-	1000mΩ
BatTemo	omp	0-50	00mV/°C
VConstvo	olt		0-850V
VDiSchg	End		0-850V
Parallel 0	0-25V		
VPackNo	orm		0-85V
VPackEr	0-85V		
VPackEr	0-85V		
VPackMa	0-85V		
VPackMi	0-85V		
VPackCh	0-85V		
VPackDi:	sChgEn	d	0-85V


- 1. Lead-acid battery manufacturer.
- 2. Capacity range.
- 3. Resistance compensation.
- 4. Temperature compensation.
- 5. Constant voltage charging voltage.
- 6. Discharge termination voltage.
- 7. Number of batteries in series.
- 8. One lead-acid battery voltage rating.
- 9. One lead-acid battery emergency charging starting voltage.
- 10. One lead-acid battery emergency charging stop voltage.
- 11. One lead-acid battery voltage overvoltage threshold.
- 12. One lead-acid battery voltage undervoltage threshold.
- 13. One lead-acid battery voltage charging upper limit.
- 14. The lower limit of the discharge voltage of a lead-acid battery.



Note:

After the parameter setting is completed, you need to save the "V" in the lower right corner of the screen.

5.3.6 Energy Management System (EMS Param)






Note

For detailed introduction of each mode, please refer to chapter 3.2 of the user manual




5.3.7 Time of Use



Note:

After the parameter setting is completed, you need to save the "V" in the lower right corner of the screen.


5.3.8 AC Charging




to save the "V" in the lower right corner of the screen.



5.3.9 Forced Charging




5.3.10 Forced Discharging





5.3.11 Protection Parameters




- 1. Insulation resistance detection.
- 2. Leakage current detection.
- 3. Ground detection.
- 4. Restart enable.
- 5. Impedance lower limit.
- 6. Grid level one overvoltage protection value.
- 7. Power grid first-level undervoltage protection value.
- 8. The first-level high-frequency protection value of the power grid.
- 9. The first-level low frequency protection value of the power grid.
- 10. Power grid first-level overvoltage protection time.
- 11. Power grid first-level undervoltage protection time.
- 12. Power grid first-level high-frequency protection time.
- 13. Power grid first-level low frequency protection time.



Note:


After the parameter setting is completed, you need to save the "V" in the lower right corner of the screen.

5.3.12 Multi-machine in Parallel












- 1. Only slave can choose address.
- 2. After the parameter setting is completed, you need to save the "V" in the lower right corner of the screen.

5.3.13 Diesel Generator Setting



6. Power ON/OFF

Please check the following requirements before testing:

- Installation location is suitable according to Chapter 4.1.3.
- · All electrical wires are connected tightly, including PV modules, battery and AC side(Such as the grid side, EPS side, Gen side).
- · Earth line and Smart meter/CT line are connected.
- · AF-DH hybrid inverters should be set according to the required local grid standard.
- · More information please contact with Afore or distributors.

6.1 Power ON

- · Turn on DC switch.
- After LCD lighting, hybrid inverter should be set following Chapter 5.3 at the first time.
- When inverter running under normal mode, Running indicator will light up(Ref. to Chapter 5.1).

6.2 Power OFF

· Turn off DC switch (in hybrid inverter) and all extra-breaker.



Note:

Hybrid inverter should be restarted after 5 minutes.

6.3 Restart

Restart Hybrid inverter, please follow steps as below:

- · Shutdown the inverter Ref. to Chapter6.2.
- · Start the inverter Ref. to Chapter 6.1.

7. Maintenance & Trouble Shooting

7.1 Maintenance

Periodically maintenance are necessary, please follow steps as below.

- · PV connection: twice a year
- AC connection(Grid and EPS): twice a year
- · Battery connection: twice a year
- · Earth connection: twice a year
- · Heat sink: clean with dry towel once a year

7.2 Trouble Shooting

The fault messages are displayed when fault occurs, please check trouble shooting table and find related solutions.

Fault Code and Trouble Shooting

Type of Fault	Code	Name	Description	Recommend Solution	
	A01	PvConnectFault	PV connection type different from setup	Check PV modules connection Check PV Mode setup Ref. Chapter 5.3.	
	A02	IsoFault	ISO check among PV panels/ wires and ground is abnormal.	Check PV modules wires, those wires are soaked or damaged, and then carry out rectification. if the fault occurs continuously and frequently, please ask help for local distributors.	
	A03	PvAfciFault	PV current arcing	Check PV modules wires and connectors broken or loose connect, and then carry out rectification. If the fault occurs continuously and frequently, please ask help for local distributors.	
	A04	Pv1OverVoltFault			
	A05	Pv2OverVoltFault			
	A06	Pv3OverVoltFault			
	A07	Pv4OverVoltFault			
PV Fault	A08	Pv5OverVoltFault			
	A09	Pv6OverVoltFault	PV Voltage over	 Reconfiguration of PV strings, reduction the PV number of a PV string to reducin 	
	A10	Pv7OverVoltFault	I v voltage over	inverter PV input voltage. • Suggestion that contacting with local	
	A11	Pv8OverVoltFault		distributors.	
	A12	Pv9OverVoltFault			
	A13	Pv10OverVoltFault			
	A14	Pv11OverVoltFault			
	A15	Pv12OverVoltFault			
	A16	PV1ReverseFault			
	A17	PV2ReverseFault		Check PV(+) and PV(-) Connect	
	A18	PV3ReverseFault	PV(+) and PV(-) reversed	whether reversed or not. • If reversed, make correction.	
	A19	PV4ReverseFault	Connection		
	A20	PV5ReverseFault			
	A21	PV6ReverseFault			

Type of Fault	Code	Name	Description	Recommend Solution		
	A22	PV7ReverseFault				
	A23	PV8ReverseFault				
	A24	PV9ReverseFault				
	A25	PV10ReverseFault				
	A26	PV11ReverseFault				
	A27	PV12ReverseFault				
	A33	Pv1AbnormalFault				
	A34	Pv2AbnormalFault				
	A35	Pv3AbnormalFault				
	A36	Pv4AbnormalFault				
	A37	Pv5AbnormalFault				
	A38	Pv6AbnormalFault				
	A39	Pv7AbnormalFault				
	A40	Pv8AbnormalFault	PV(+) and PV(-) reversed Connection			
PV Fault	A41	Pv9AbnormalFault				
	A42	Pv10AbnormalFault				
	A43	Pv11AbnormalFault		Check PV modules partial occlusion or cells damaged. Check PV module wires and connectors broken or loose connect, then repair it.		
	A44	Pv12AbnormalFault				
	A45	Pv13AbnormalFault				
	A46	Pv14AbnormalFault				
	A47	Pv15AbnormalFault				
	A48	Pv16AbnormalFault				
	A49	Pv17AbnormalFault				
	A50	Pv18AbnormalFault				
	A51	Pv19AbnormalFault				
	A52	Pv20AbnormalFault				
	A53	Pv21AbnormalFault				
	A54	Pv22AbnormalFault				
	A55	Pv23AbnormalFault				
	A56	Pv24AbnormalFault				

Type of Fault	Code	Name	Description	Recommend Solution		
	B01	PcsBatOverVoltFault		Check inverters connected battery lines		
	B02	PcsBatUnderVoltFault	Battery voltage over or under	and connectors broken or loose connect. Carry out rectification if broken or loose. Checking battery voltage is abnormal		
	B03	PcsBatInsOverVoltFaul		or not, then maintenance or change new battery.		
	B04	PcsBatReversedFault	Bat. (+) and Bat. (-) are reversed.	Check Bat.(+) and Bat.(-)connect reversed or not. Make correction If reversed.		
	B05	PcsBatConnectFault	Battery wires loose	Check battery wires and connectors damage or loose connect. Carry out rectification if break.		
	B06	PcsBatComFault	Battery communication abnormal	Check battery side communication wires damage or loose connect, and then carry out rectification. Check battery is off or other abnormal, then Mastertenance battery or change new battery.		
	B07	PcsBatTempSensorOpen	Battery temperature	Check battery temperature sensor and connected wires damage or not , then		
	B08	PcsBatTempSensorShort	sensor abnormal	rectification or change new one.		
Battery Fault	B09	BmsBatSystemFault				
	B10	BmsBatVolOverFault				
	B11	BmsBatVolUnderFault				
	B12	BmsCellVolOverFault				
	B13	BmsCellVolUnderFault				
	B14	BmsCellVolUnbanceFau				
	B15	BatChgCurOverFault		If specific fault high temperature or low temperature, then should change battery		
	B16	BatDChgCurOverFault	All these faults will be	installed environment temperature. • Restart battery, maybe can working as		
	B17	BatTemperatureOverFa	detected or reported by battery BMS.	normal. • If this fault occurs continuously and		
	B18	BatTemperatureUnderF		frequently, please ask help for local distributors.		
	B19	CelTemperatureOverFa				
	B20	CelTemperatureUnderF				
	B21	BatlsoFault				
	B22	BatSocLowFault				
	B23	BmsInterComFault				
	B24	BatRelayFault				

Type of Fault	Code	Name	Description	Recommend Solution
	B25	BatPreChaFault		
	B26	BmsBatChgMosFault		
	B27	BmsBatDChgMosFault		
	B28	BMSVolOVFault		
	B29	BMSVolLFault		
	B30	VolLockOpenFault		
	B31	VolLockShortFault		
	B32	ChgRefOVFault		
	C01	GridLossFault	Grid lost (islanding)	Inverter will restart automatically when the grid return to normal. Check inverter connected with grid connectors and cable normal or not.
	C02	GridUnbalanVoltFault	Grid Voltage unbalanced.	The inverter will restart automatically when the grid three phase return to normal. Check inverter connected with the grid connectors and wires normal or not.connectors and cable normal or not.
Battery Fault	C03	GridInstOverVoltFault	Grid instantaneous voltage over	The inverter will restart automatically when the grid three phase return to normal. Contact with local distributor or required grid company adjust protection parameters.
	C04	Grid10MinOverVoltFault	Grid voltage Over by 10 Minutes	The inverter will restart automatically when the grid three phase return to normal. Contact with local distributor or required grid company adjust 10 minutes protection voltage parameters.
	C05	GridOverVoltFault	Grid voltage over	
	C06	GridUnderVoltFault	Grid voltage under	The inverter will restart automatically when the grid three phase return to normal.
	C07	GridLineOverVoltFault	Grid line voltage over	Contact with local distributor or required grid company adjust voltage protection parameters.
	C08	GridLineUnderVoltFault	Grid line voltage under	
	C09	GridOverFreqFault	Grid Frequency over	The inverter will restart automatically when the grid three phase return to normal.
	C10	GridUnderFreqFault	Grid Frequency under	Contact with local distributor or required grid company adjust frequency protection parameters.

Type of Fault	Code	Name	Description	Recommend Solution		
	D01	UpsOverPowerFault	Off-grid load over	Reduce loads. If sometimes overload, it can be ignored, when generation power enough can be recovery. If those faults occurs continuously and frequently, please ask help for local distributors.		
Off-grid Fault	D02	GridConflictFault	Grid connected to Back-up terminal	Check the off-grid port connection correct, disconnect both off-grid and grid ports.		
	D03	GenOverVoltFault	GenOverVoltFault	Adjust generator running parameters,		
	D04	GenUnderVoltFault	GenUnderVoltFault	make the output voltage, frequency in allowed range.		
	D05	GenOverFreqFault	GenOverFreqFault	If this fault occurs continuously and frequently, please ask help for local		
	D06	GenUnderFreqFault	GenUnderFreqFault	distributors.		
	E01	Pv1HwOverCurrFault				
	E02	Pv2HwOverCurrFault				
	E03	Pv3HwOverCurrFault				
	E04	Pv4HwOverCurrFault				
	E05	Pv5HwOverCurrFault		Power off, then restart (Ref. Chapter8). If those faults occurs continuously and frequently, please ask help for local		
	E06	Pv6HwOverCurrFault	PV current over, triggered by hardware protection			
	E07	Pv7HwOverCurrFault	circuit	distributors.		
	E08	Pv8HwOverCurrFault				
	E09	Pv9HwOverCurrFault				
DC Fault	E10	Pv10HwOverCurrFault				
	E11	Pv11HwOverCurrFault				
	E12	Pv12HwOverCurrFault				
	E13	Pv1SwOverCurrFault				
	E14	Pv2SwOverCurrFault				
	E15	Pv3SwOverCurrFault				
	E16	Pv4SwOverCurrFault	PV current over, triggered	Power off, power on then restart. If those faults occurs continuously and		
	E17	Pv5SwOverCurrFault	by Software logic.	frequently, please ask help for local distributors.		
	E18	Pv6SwOverCurrFault		a.c.aoutoro.		
	E19	Pv7SwOverCurrFault				
	E20	Pv8SwOverCurrFault				

Type of Fault	Code	Name	Description	Recommend Solution		
	E21	Pv9SwOverCurrFault				
	E22	Pv10SwOverCurrFault				
	E23	Pv11SwOverCurrFault				
	E24	Pv12SwOverCurrFault				
	E33	Boost1SelfCheck(boost)Fault				
	E34	Boost2SelfCheck(boost)Fault				
	E35	Boost3SelfCheck(boost)Fault				
	E36	Boost4SelfCheck(boost)Fault				
	E37	Boost5SelfCheck(boost)Fault				
	E38	Boost6SelfCheck(boost)Fault	PV boost circuit abnormal	Power off, then restart (Ref. Chapter8).If those faults continuously and		
	E39	Boost7SelfCheck(boost)Fault	when self checking	frequently, please ask help for local distributors.		
	E40	Boost8SelfCheck(boost)Fault				
	E41	Boost9SelfCheck(boost)Fault				
	E42	Boost10SelfCheck(boost)Fault				
DC Fault	E43	Boost11SelfCheck(boost)Fault				
	E44	Boost12SelfCheck(boost)Fault				
	E45	BusHwOverVoltFault				
	E46	BusHwOverHalfVoltFault				
	E47	BusSwOverVoltFault	Bus voltage over	Power off, then restart (Ref. Chapter8).If those faults continuously and		
	E48	BusSwOverHalfVoltFault		frequently, please ask help for local distributors.		
	E49	BusSwUnderVoltFault	Bus voltage under as running			
	E50	BusUnbalancedFault	DC Bus voltage unbalanced			
	E51	BusBalBridgeHwOver- CurFault				
	E52	BusBalBridgeSwOver- CurFault	Bus Controller current over	Power off, then restart (Ref. Chapter8). If those faults continuously and frequently, please ask help for local		
	E53	BusBalBridgeSelf- CheckFault	Bus Controller abnormal when self checking	distributors.		
	E54	BDCHwOverCurrFault	BiDC current over			
	E55	BDCSwOverCurrFault	DIDO CUITETIL OVEI	Power off, then restart (Ref. Chapter8).		
	E56	BDCSelfCheckFault	BiDC abnormal as self checking	If those faults continuously and frequently, please ask help for local		
	E57	BDCSwOverVoltFault	BiDC voltage over	distributors.		
	E58	TransHwOverCurrFault	BiDC current over			

Type of Fault	Code	Name	Description	Recommend Solution		
	E59	BDCFuseFault	BiDC fuse broken	Change fuse.		
	E60	BDCRelayFault	BiDC relay abnormal	Power off, then restart (Ref. Chapter8). If those faults continuously and frequently, please ask help for local distributors.		
	F01	HwOverFault	All over current/ voltage by protection hardware			
	F02	InvHwOverCurrFault	Ac over current by protection hardware			
	F03	InvROverCurrFault	R phase current over	Power off, then restart (Ref. Chapter8).If those faults occurs continuously and		
	F04	InvSOverCurrFault	S phase current over	frequently, please ask help for local distributors.		
	F05	InvTOverCurrFault	T phase current over			
	F06	GridUnbalanCurrFault	On-grid current unbalanced			
	F07	DcInjOverCurrFault	DC injection current over			
AC Fault	F08	AcOverLeakCurrFault	Ac side leakage current over	Check AC insulation and ground wires connect ground is well or not, then repair it. Power off, then restart (Ref. Chapter8). If those fault occurs continuously and frequently, please ask help for local distributors.		
	F09	PLLFault	PLL abnormal			
	F10	GridRelayFault	Grid relay abnormal	Power off, then restart (Ref. Chapter8)		
	F11	UpsRelayFault	Ups relay abnormal	 If those fault occurs continuously and frequently, please ask help for local distributors. 		
	F12	GenRelayFault	Generator relay abnormal			
	F13	Relay4Fault	Relay4 abnormal			
	F14	UpsROverCurrFault		When off-grid the load start impulse current is over, reduce the start impulse		
	F15	UpsSOverCurrFault	Off-grid output current over	current load. • Power off, then restart (Ref. Chapter8). • If those fault occurs continuously and		
	F16	UpsTOverCurrFault		frequently, please ask help for local distributors.		
	F17	GenROverCurrFault				
	F18	GenSOverCurrFault	Generator current over	 Check generator output voltage, frequency is stability, and adjust generator. 		
	F19	GenTOverCurrFault		Power off, then restart(Ref. Chapter8).If those fault occurs continuously and		
	F20	GenReversePowerFault	Active power injected to generator	frequently, please ask help for local distributors.		

Type of Fault	Code	Name	Description	Recommend Solution	
	F21	UpsOverVoltFault	Off-grid output voltage over		
	F22	UpsUnderVoltFault	or under		
AC Fault	F23	UpsOverFreqFault	Off-grid output frequency	Power off, then restart (Ref. Chapter8). If those faults occurs continuously and frequently, please ask help for local	
	F24	UpsUnderFreqFault	over or under	distributors.	
	F25	DcInjOverVoltFault	Off-grid DC injection voltage over		
	G01	PV1CurAdChanFault			
	G02	PV2CurAdChanFault			
	G03	PV3CurAdChanFault			
	G04	PV4CurAdChanFault			
	G05	PV5CurAdChanFault			
	G06	PV6CurAdChanFault			
	G07	PV7CurAdChanFault			
	G08	PV8CurAdChanFault			
	G09	PV9CurAdChanFault			
	G10	PV10CurAdChanFault			
	G11	PV11CurAdChanFault			
System Fault	G12	PV12CurAdChanFault	Sampling hardware	Power off, then restart (Ref. Chapter8). If those faults occurs continuously and	
System : dan	G13	BDCCurrAdChanFault	abnormal	frequently, please ask help for local distributors.	
	G14	TransCurAdChanFault			
	G15	BalBrigCurAdChanFault			
	G16	RInvCurAdChanFault			
	G17	SInvCurAdChanFault			
	G18	TInvCurAdChanFault			
	G19	RInvDciAdChanFault			
	G20	SInvDciAdChanFault			
	G21	TInvDciAdChanFault			
	G22	LeakCurAdChanFault			
	G23	VoltRefAdChanFault			
	G24	UpsRCurAdChanFault			

Type of Fault	Code	Name	Description	Recommend Solution		
	G25	UpsSCurAdChanFault				
	G26	UpsTCurAdChanFault				
	G27	GenRCurAdChanFault				
	G28	GenSCurAdChanFault				
	G29	GenTCurAdChanFault				
	G30	UpsRDcvAdChanFault				
	G31	UpsSDcvAdChanFault				
	G32	UpsTDcvAdChanFault				
	G37	TempAdChanFault	All temperature sensors abnormal			
	G38	VoltAdConflictFault	The sample value of PV, battery and BUS voltage inconsistent	Power off, then restart (Ref. Chapter8). If those faults occurs continuously and		
System Fault	G39	CPUAdConflictFault	The sample value between master CPU and slaver CPU inconsistent	frequently, please ask help for loca distributors.		
	G40	PowerCalcConflictFault	Power value between PV, battery and AC output inconsistent			
	G41	EnvirOverTempFault	Installation environment			
	G42	EnvirLowTempFault	temperature over or low			
	G43	CoolingOverTempFault	Cooling temperature over	Change or improve the installation environment temperature, make running temperature suitable. Power off, then restart (Ref. Chapter8)		
	G44	CoolingLowTempFault	or low			
	G45	OverTemp3Fault		If those faults occurs continuously and frequently, please ask help for local		
	G46	LowTemp3Fault	Temperature3 over or low	distributors.		
	G47	CpuOverTempFault	CPU temperature over			
				Power off, then restart (Ref. Chapter8).		
	G48	ModelConflictFault	Version conflict with inverter	If those faults occurs continuously and frequently, please ask help for local distributors.		
	101	InterFanWarning		Pemove foreign metter legged in fee		
	102	ExterFanWarning		Remove foreign matter logged in fan. If those faults occurs continuously and frequently, please ask help for local distributors.		
	103	Fan3Warning				



Type of Fault	Code	Name	Description	Recommend Solution		
	104	EnvirTempAdChan- Warning		The warnings are not matter influence.		
	105	CoolingTempAdChan- Warning	Some temperature sensors abnormal	 Power off, then restart (Ref. Chapter8). If those faults occurs continuously and frequently, please ask help for local 		
	106	Temp3AdChanWarning		distributors.		
	107	ExtFlashComWarning	Flash abnormal			
Inner Warnning	108	EepromComWarning	Eeprom abnormal			
	109	SlaveComWarning	Communication between slaver CPU and master CPU abnormal	Power off, then restart (Ref. Chapter8). If this those faults continuously and frequently, please ask help for local distributors.		
	I10	HmiComWarning	HMI abnormal			
	l11	FreqCalcConflictWarning	Frequency value abnormal			
	I12	UnsetModel	Running model is not initial	Contact with local distributor.		
	J01	MeterComWarning	Meter/CT abnormal	Check the smart meter model, connection or connectors are correct, any loose. if abnormal, repair or change. Power off, then restart (Ref. Chapter8). if those faults occurs continuously and frequently, please ask help for local distributors.		
	J02 MeterConnectWarning		Wires connecting type of meter wrong	Check Meter/CT connection, installed place, and installed direction. If abnormal, re-installation. Power off, then restart (Ref. Chapter8). If this those faults continuously and frequently, please ask help for local distributors.		
Outside Warnning	J03	SohWarning	Battery SOH low	Contact with Battery manufacturer.		
	J04	GndAbnormalWarning	Earth impedance over by cable loose and so on	Check earth line connection or earth connecting impedance. if abnormal, then adjust it. Power off, then restart (Ref. Chapter8). If this those faults continuously and frequently, please ask help for local distributors.		
Inner Warnning	J05	ParallelComWarning	Communication between master inverter and slaver Fanebrationmal in parallel mode	Check parallel connect communication wires damage, connectors loose, connect port correct or not. if not, then adjust it. Power off, then restart (Ref. Chapter8). If this those faults continuously and frequently, please ask help for local distributors.		





8. Specifications

PV Input	AF3K-DH	AF3.6K-DH	AF4K-DH	AF4.6K-DH	AF5K-DH	AF5.5K-DH
Max. Input Power (kW)	4.5	5.4	6.0	6.9	7.5	8.3
Max. PV Voltage (V)				00		
MPPT Range (V)			80	- 550		
Normal Voltage (V)				60		
Startup Voltage (V)			1	00		
Max. Input Current (A)			15.	5 x 2		
Max. Short Current (A)			26.	0 x 2		
No. of MPP Tracker / No. of PV String				/2		
Battery						
Max. Charge/Discharge Power (kW)	4.5 / 4.5	5.4 / 5.4	6.0 / 6.0	6.9 / 6.9	7.5 / 7.5	8.3 / 8.3
Max. Charge/Discharge Current (A)	4.57 4.5	3.47 3.4		50	7.57 7.5	0.5 / 0.5
Battery Normal Voltage (V)				30		
Battery Voltage Range (V)				- 495		
Battery Type				Lead-acid		
AC Grid			LI-IOII / I	Leau-aciu		
Max. Continuous Power (kVA)	3.0	3.6	4.0	4.6	5.0	5.5
Max. Continuous Current (A)	15	17.5	19.5	22.5	24.5	27
Nominal Grid Voltage (V)	13			/ 183 to 229 @ 208	24.5	21
Nominal Grid Frequency (Hz)		4		7 183 to 229 @ 208 50		
Output Power Factor		4 4-6			!\	
Current THD (%)		1 detau		0.8 leading to 0.8 la	gging)	
	AESK DH	AES EK DH		3 AF4 CK DH	AFEK DH	AFF EK DU
Gen Input&AC Back-up	AF3K-DH	AF3.6K-DH 17.5	AF4K-DH 19.5	AF4.6K-DH 22.5	24.5	AF5.5K-DH
Max. Continuous Current (A)	13					
Max. Continuous Power (kVA)	3.0	3.6	4.0	4.6	5.0	5.5
Max. Peak Current (A) (10min)	18.8 / 21.7	22.5 / 26.0	25 / 28.9	28.8 / 33.2	31.3 / 36.1	34.6 / 39.9
Max. Peak Power (kVA) (10min)	4.5 / 4.5	5.4 / 5.4	6.0 / 6.0	6.9 / 6.9	7.5 / 7.5	8.3 / 8.3
Nominal AC Voltage L-L (V)				/ 208		
Nominal AC Voltage L-O (V)				/ 104		
Nominal AC Frequency (Hz)				50		
Switching Time (ms)				10		
Voltage THD (%)			•	: 3		
Efficiency						
CEC Efficiency (%)				7.0		
Max. Efficiency (%)				7.6		
PV to Bat. Efficiency (%)				8.1		
Bat. between AC Efficiency (%)				6.8		
Protection	AF3K-DH	AF3.6K-DH	AF4K-DH	AF4.6K-DH	AF5K-DH	AF5.5K-DH
PV Reverse Polarity Protection				'es		
Bat. Reverse Polarity Protection				'es		
Over Current/Voltage Protection				'es		
Anti-Islanding Protection				'es		
AC Short Circuit Protection				'es		
Residual Current Detection				'es		
Ground Fault Monitoring				'es		
Insulation Resister Detection				'es		
PV Arc Detection				'es		
Rapid Shut Down				'es		
Protection Degree				NEMA4X		
General Data	AF3K-DH	AF3.6K-DH	AF4K-DH	AF4.6K-DH	AF5K-DH	AF5.5K-DH
Dimensions (W x H x D)				m / 15.7 x 23.6 x 9.0 in		
Weight				/ 55 lbs		
Topology				rmerless		
Cooling	Natural Convection					
Relatively Humidity	0 - 100 %					
Operating Temperature Range	- 25 to 60 °C / -77 to 140 °F					
Operating Altitude	< 4000 m / < 13123 ft					
Noise Emission (dB)	< 25					
Standby Consumption (W)	< 10					
Mounting		Wall Bracket				
Communication with RSD			SUN	ISPEC		
Display & Communication Interfaces			LCD, LED, RS48	5, CAN, Wi-Fi, 4G		
Certification & Approvals	UL 1741 SA, UL 17	741, UL1699B, UL 199	98, IEEE1547, IEEE1	547A, IEEE1547.1, CSA	22.2 No.107, Rule	21, HECO Rule 14
certification a ripproveis						



2011	AECK DII	A FTIV DIL	A E Z C K D L L	A FOY DIL	A EQ CK DIL	AFO CK DII	
PV Input	AF6K-DH	AF7K-DH	AF7.6K-DH	AF8K-DH	AF8.6K-DH	AF9.6K-DH	
Max. Input Power (kW)	9.0	10.5	11.4	12.0	12.9	15.0	
Max. PV Voltage (V)				00			
MPPT Range (V)				- 550			
Normal Voltage (V)				60			
Startup Voltage (V)			1	00			
Max. Input Current (A)	15.5 x 2			15.5 x 3			
Max. Short Current (A)	26.0 x 2			26.0 x 3			
No. of MPP Tracker / No. of PV String	2/2			3/3			
Battery							
Max. Charge/Discharge Power (kW)	9.0 / 9.0	10.5 / 10.3	11.4 / 10.3	11.5 / 10.3	11.5 / 10.3	11.5 / 10.3	
Max. Charge/Discharge Current (A)				50			
Battery Normal Voltage (V)				30			
Battery Voltage Range (V)				495			
Battery Type				_ead-acid			
AC Grid			2, 1011 / 1	caa acia			
Max. Continuous Power (kVA)	6.0	7.0	7.6	8.0	8.6	9.6	
Max. Continuous Current (A)	29.0	34.0	37	39	41.5	46.5	
	29.0	34.0			1-10	40.5	
Nominal Grid Voltage (V)				/ 183 to 229 @ 208	8		
Nominal Grid Frequency (Hz)				50			
Output Power Factor		1 defa	ault (adjustable from	-	lagging)		
Current THD (%)				3			
Gen Input&AC Back-up	AF6K-DH	AF7K-DH	AF7.6K-DH	AF8K-DH	AF8.6K-DH	AF9.6K-DH	
Max. Continuous Current (A)	29.0	34.0	37	39	41.5	46.5	
Max. Continuous Power (kVA)	6.0	7.0	7.6	8.0	8.6	9.6	
Max. Peak Current (A) (10min)	37.5 / 43.3	43.8 / 49.5	47.5 / 49.5	47.9 / 49.5	47.9 / 49.5	47.9 / 49.5	
Max. Peak Power (kVA) (10min)	9.0 / 9.0	10.5 / 10.3	11.4 / 10.3	11.5 / 10.3	11.5 / 10.3	11.5 / 10.3	
Nominal AC Voltage L-L (V)			240	/ 208			
Nominal AC Voltage L-O (V)			120	/ 104			
Nominal AC Frequency (Hz)			6	50			
Switching Time (ms)			<	10			
Voltage THD (%)			<	: 3			
Efficiency							
CEC Efficiency (%)			9	7.0			
Max. Efficiency (%)				7.6			
PV to Bat. Efficiency (%)				8.1			
Bat. between AC Efficiency (%)				5.8			
Protection	AF6K-DH	AF7K-DH	AF7.6K-DH	AF8K-DH	AF8.6K-DH	AF9.6K-DH	
PV Reverse Polarity Protection	AFOR-DH	AF/K-DH		es	AF6.0K-DH	AF3.0K-DH	
Bat. Reverse Polarity Protection				es			
Over Current/Voltage Protection				es			
				es			
Anti-Islanding Protection AC Short Circuit Protection				es			
				es			
Residual Current Detection			·				
Ground Fault Monitoring				es es			
Insulation Resister Detection							
PV Arc Detection				es			
Rapid Shut Down				es			
Protection Degree				NEMA4X			
General Data	AF6K-DH	AF7K-DH	AF7.6K-DH	AF8K-DH	AF8.6K-DH	AF9.6K-DH	
Dimensions (W x H x D)			400 x 600 x 229 mr	n / 15.7 x 23.6 x 9.0 in	1		
Weight			25 kg	/ 55 lbs			
Topology			Tranfo	rmerless			
Cooling	Natural Convection		Intellig	ent Fan			
Relatively Humidity				.00 %			
Operating Temperature Range		- 25 to 60 °C / -77 to 140 °F					
Operating Altitude		< 4000 m / < 13123 ft					
Noise Emission (dB)	< 25			40			
Standby Consumption (W)				10			
Mounting	₹ 10 Wall Bracket						
Communication with RSD		Wall Bracket SUNSPEC					
Display & Communication Interfaces				5, CAN, Wi-Fi, 4G			
	III 1744 CA 1:: 1	741 111 16000 111			CA 22 2 No 407 C 1	21 UECO 2011-11	
Certification & Approvals	UL 1/41 SA, UL 1	741, UL1699B, UL 1	998, IEEE1547, IEEE1		SA 22.2 No.107, Rule	ezi, HECO Rule 14	
EMC			FCC part15 CLASS B				