

Three phase Hybrid Inverter

www.aforeenergy.com



Version: HT1395-01



Afore New Energy Technology (Shanghai) Co., Ltd.

T +86-21-54326236 F +86-21-54326136 E info@aforeenergy.com

Ad Building 7, No.333 Wanfang Rd, Minhang District, Shanghai, China. 201112



Afore New Energy Technology (Shanghai) Co., Ltd.

Contents

1. About This Manual	1
1.1 Scope of Validity	1
1.2 Target Group	1
2. Safety & Symbols	1
2.1 Safety Precautions	1
2.2 Explanations of Symbols	2
3. Introduction.	2
3.1 Basic Instruction	2
3.2 Operation Modes	3
3.2.1 Self-Use	3
3.2.2 Time of Use	4
3.2.3 Selling First	6
3.2.4 Back-Up	6
4. Installation.	7
4.1 Pre-installation	7
4.1.1 Unpacking & Package List	7
4.1.2 Product Overview	8
4.1.3 Transportation and Storage	9
4.1.4 Mounting Location	10
4.2 Mounting	11
4.3 Electrical Connection	12
4.3.1 PV Connection	13
4.3.2 Battery Connection.	14
4.3.2.1 BAT-CAN/RS485.	17
4.3.3 AC Connection.	18
4.3.4 DRM	20
4.3.5 CT or Meter Connection	21
4.4 Communication Connection	22
4.5 Earth Connection	24

5. Operation	25
5.1 Control Panel	25
5.2 Menu Overview	26
5.3 Inverter Setting	26
5.3.1 Time & Date	27
5.3.2 Safety	27
5.3.3 Lithium Battery	28
5.3.4 PV Mode	28
5.3.5 Lead Acid	29
5.3.6 Energy Management System (EMS Param)	29
5.3.7 Timing of Use	30
5.3.8 AC Charging	31
5.3.9 Forced Charging	31
5.3.10 Forced Discharging.	32
5.3.11 Protection Parameters	33
5.3.12 DRM Setting (DRMS)	34
5.3.13 Ground detection	35
5.3.14 Enable Power Quality Response Modes	35
5.3.15 Disable Power Quality Response Modes.	39
5.3.16 Active Power Mode Set.	40
5.3.17 Frequency protection range (Freq Range) Setting.	41
5.3.18 Voltage protection range (Volt Range) set	42
5.3.19 Version	43
5.3.20 Install Dual.Meters	43
5.3.21 Active anti-islanding protection.	44
6. Power ON/OFF	44
6.1 Power ON	44
6.2 Power OFF	44
6.3 Restart	44
7. Maintenance & Trouble Shooting	45
7.1 Maintenance	45
7.2 Trouble Shooting	45
8. Specifications	56

1.About This Manual

1.1 Scope of Validity

This manual mainly describes the product information, guidelines for installation, operation, maintenance and troubleshooting. And this manual applies to Afore Three phase Hybrid Inverter.

AF3K-TH	AF4K-TH	AF5K-TH	AF6K-TH	AF8K-TH	AF10K-TH
AF12K-TH	AF15K-TH	AF17K-TH	AF20K-TH	AF25K-TH	AF30K-TH

Please keep this manual available all the time in case of any emergency.

1.2 Target Group

This manual is for qualified personnel. The tasks described in this manual must only be performed by qualified personnel.

2.Safety & Symbols

2.1 Safety Precautions

1. All work on the inverter must be carried out by qualified electricians.
2. The PV modules shall not be functionally earthed.
- 3.The PV frame and inverter enclosure must be connected to the ground.
4. Do not touch the inverter cover until 5 minutes after disconnecting both DC and AC power supply.
5. Do not touch the inverter enclosure when operating, keep away from materials that may be affected by high temperatures.
6. Please ensure that the used device and any relevant accessories are disposed of in accordance with applicable regulations.
7. Afore inverter should be placed upwards and handled with care in delivery. Pay attention to waterproof. Do not expose the inverter directly to water, rain, snow or spray.
8. Alternative uses, modifications to the inverter not recommended. The warranty can become void if the inverter was tampered with or if the installation is not in accordance with the relevant installation instructions.
9. The RCMUs is integrated inside the inverter.
10. The product is not tested to section 5 of AS/NZS 4777.2:2020 and should not be installed in multiple inverter combinations without external devices in accordance with the requirements of AS/NZS 4777.1.

2.2 Explanations of Symbols

Afore inverter strictly comply with relevant safety standards. Please read and follow all the instructions and cautions during installation, operation and maintenance.



Danger of electric shock

The inverter contains fatal DC and AC power. All work on the inverter must be carried out by qualified personnel only.



Beware of hot surface

The inverter's housing may reach uncomfortably hot 60°C (140°F) under high power operation. Do not touch the inverter enclosure when operation.



Residual power discharge

Do not open the inverter cover until 5 minutes after disconnection both DC and AC power supply.



Important notes

Read all instructions carefully. Failure to follow these instructions, warnings and precautions may lead to device malfunction or damage.



Do not dispose of this device with the normal domestic waste.




Refer to manual before service.

3. Introduction

3.1 Basic Instruction

The Afore AF-TH Three phase Hybrid Inverters are designed to increase energy independence for homeowners. Energy management is based on time-of-use and demand charge rate structures, significantly reduce the amount of energy purchased from the public grid and optimize self-consumption.




However if an external residual current device (RCD) (type B is recommended) is mandatory, the switch must be triggered at a residual current of 300 mA (recommended). RCD of other specifications can also be used according to local standard.

To maintain the neutral continuity in standalone mode, as required by Australian safety code, the neutral cable on the AC Load output port and AC-Grid Port must be connected together.

3.2 Operation Modes

3.2.1 Self-use

The Self-Use mode is for the regions with low feed-in tariff and high electricity prices. The energy produced by the PV system is used to optimize self-consumption needs. The excess energy is used to recharge the batteries, any remaining excess is then exported to the grid.



Energy flow:

PV → Load → Battery → Grid

Note: Advance Setting

When select 0 W under P_Feed menu, the inverter will export zero energy to the grid.


When select xx W under P_Feed menu, the inverter will export customized energy to the grid.

3.2.2 Time of Use

The Time of Use mode is designed to reward customers who do their part to reduce demand on the electric grid, particularly during peak usage periods. Use most of your electricity from PV energy and during off-peak time periods, and you could significantly lower your monthly bill.

A. Charge Setting

PV Charge Mode




4 periods of time charge setting.

Energy flow:

PV → Battery → Load → Grid

AC Charge Mode



4 periods of time charge setting.

Energy flow:


PV and Grid → Battery → Load

Note:

After select AC charge, the AC will also charge the battery when the PV is low or no PV.

B. Forced discharge


4 periods of time discharge setting



Energy flow: Battery and PV → Load → Grid

C. Forbidden Discharge

4 periods of time discharge setting, the battery will be charged firstly.




Energy flow:

PV → Battery → Load → Grid

3.2.3 Selling First

The Selling First mode is suitable for the regions with high feed-in tariff.




Energy flow:

PV → Load → Grid → Battery

3.2.4 Back-Up

When the grid fails, the system will automatically switch to Back-Up mode. The back-up loads can be supplied by both PV and battery energy.



Energy flow: PV → Battery → Load → Grid

4. Installation

4.1 Pre-installation


4.1.1 Unpacking & Package List

Unpacking

On receiving the inverter, please check to make sure the packing and all components are not missing or damaged. Please contact your dealer directly for supports if there is any damage or missing components.



Package List

Open the package, please check the packing list shown as below.




No.	Qty	Items	No.	Qty	Items
1	1	Hybrid Inverter	9	3	Expansion Tube
2	1	Wall Mounting Bracket	10	3	Bracket Screw
3	1	Quick Installation Instructions	11	4	PV Terminals
4	1	Inspection Certificate	12	1	Battery Terminals
5	1	Warranty Card	13	2	AC Terminals
6	1	Monitor Quick Installtion	14	1	Monitor Module
7	1	Smart Meter	15	2	Zero-Injection Connector
8	1	Security Screw	16	3	CT (Optional)

4.1.2 Product Overview



Inverter Terminals



No.	Items	No.	Items
1	DC Switch	7	DRM Port
2	Waterproof Ventilating Valve	8	BAT Port
3	DC Connectors (+) For PV Strings	9	GRID UP
4	DC Connectors (-) For PV Strings	10	Meter Port
5	Battery Port	11	Wifi Port
6	BACK UP		

4.1.3 Transportation and Storage

If the inverter is not put into use immediately, the transportation and storage requirements needs to be met:

Transportation

- 1.The inverter must be transported in its original packaging. Afore will not be held responsible for any damage to the inverter caused by improper transportation or by transportation after it has been installed.
2. Observe the caution signs on the packaging of inverter before transportation.
3. Pay attention to the weight of the inverter. Be cautious to avoid injury when carrying the inverter.
4. Wear protective gloves when carrying the equipment by hand to prevent injuries.
- 5.When lifting up the inverter, hold the handle position of the inverter. Keep the inverter horizontal in case of falling down due to tilt.


Storage

1. The inverter must be stored indoors.
2. Do not remove the original packaging material and check the outer packaging material regularly.
3. Stack the inverter in accordance with the caution signs on the inverter carton to prevent their falling down and device damage. Do not place it upside down.

4.1.4 Mounting Location

The inverters are designed for indoor and outdoor installation (IP65), to increase the safety, performance and lifespan of the inverter, please select the mounting location carefully based on the following rules:


- The inverter should be installed on a solid surface, far from flammable or corrosion materials, where is suitable for inverter's weight and dimensions.
- The ambient temperature should be within $-25^{\circ}\text{C} \sim 60^{\circ}\text{C}$ (between -13°F and 140°F).
- The installation of inverter should be protected under shelter. Do not expose the inverter to direct sunlight, water, rain, snow, spray lightning, etc.




- The inverter should be installed vertically on the wall, or lean back on plane with a limited tilted angle. Please refer to below picture.
- Leave the enough space around inverter, easy for accessing to the inverter, connection points and maintenance.
- Reserve enough clearance around the inverter to ensure sufficient space for heat dissipation, Clearance requirement and multiple installation.

4.2 Mounting


Step 1



The recommended torque value is 8 N · m.





Step 2




Step 3

The recommended torque value is 1.2 N · m.



4.3 Electrical Connection



4.3.1 PV Connection


The AF-TH series hybrid inverter has one/two MPPT channels, can be connected with one/two strings of PV panels. Please make sure below requirements are followed before connecting PV panels and strings to the inverter:

- The open-circuit voltage and short-circuit current of PV string should not exceed the reasonable range of the inverters.
- ⚡ The isolation resistance between PV string and ground should exceed 300 kΩ.
- The polarity of PV strings are correct.
- Use the DC plugs in the accessory.
- The lightning protector should be equipped between PV string and inverter.
- Disconnect all of the PV (DC) switch during wiring.

Warning:

The fatal high voltage may on the DC side, please comply with electric safety when connecting.
Please make sure the correct polarity of the cable connected with inverter, otherwise inverter could be damaged.


Step 1



Note:

PV cable suggestion
Cross-section
4mm²

Step 2



Note:


Please use PV connector crimper to pinch the point of the arrow.



Note:

You'll hear click sound when the connector assembly is correct.

Step 3




Step 4

Insert the disassembly tool into the blue gap and unlock it.



Warning:

Special tools are required when disassembling terminals, and manual disassembly is not possible.




4.3.2 Battery Connection

AF-TH series hybrid inverters are compatible with lithium battery. For lead acid battery or batteries with other brands, please confirm with local distributor or Afore for technical support.




Note:


Set battery type and manufacturer, please refer to Chapter 5.3. BMS(Battery Management System)communication is needed between inverter and battery.

Step 1

Step 2


Pass the crimped battery harness through the waterproof connector and the cover.


Step 3

Insert the wire harness into the terminals according to “+” and “-” polarity, make the insulated terminals parallel with the terminals, the crimping screw torque is $2.0 \pm 0.1 \text{ N.m}$



Step 4

A “click” sound will be heard when the connector assembly is correct.




Step 5

Use an open-end wrench to tighten the waterproof lock.




Step 6

Insert the battery connector into the inverter, if hear a “click”, it means the battery connection is finished.



Step 7




Warning:

Special tools are required when disassembling terminals, and manual disassembly is not possible.


4.3.2.1 Lithium battery communication connection

The inverter uses CAN to communicate with the battery's BMS. The image below shows the assembly of the CAN communication cables.



4.3.2.2 Lead acid battery-NTC

The NTC cable enables the communication between the inverter and Lead batteries.



Note:

1. NTC (including connection line) is provided by battery manufacturers.
2. The user needs to check with battery manufacturer for the position to place the sensor.
3. The NTC is external, and there is no NTC connection port on the lead -acid battery. NTC is used to test the working environment temperature of lead -acid batteries.
4. If installing Afore inverter with lead acid batteries please checkwith Afore inverter for advice regarding charge settings.

4.3.3 AC Connection

The AC terminal contains “GRID” and “BACK-UP”, GRID for load, and BACK-UP for emergency load.

Before connecting, a separate AC breaker between individual inverter and AC input power is necessary. This will ensure the inverter be securely disconnected during maintenance and fully protected from current of AC input.

An extra AC breaker is needed for On-Grid connection to be isolated from grid when necessary. Below are requirements for the On-Grid AC-breaker.

Inverter Model	AC breaker specification
AF3K~12K-TH	63A/230V/400V AC breaker
AF15~20K-TH	125A/230V/400V AC breaker



Note:


Qualified electrician will be required for the wiring.

Model	Wire Size	Cable (mm ²)	Torque value
3-20kW	8-10AWG	4-6	1.2N·m

Please follow steps for AC connection

- Connect AC protector or breaker first before connecting.
- remove insulation sleeve 11mm(0.5 inch) length, unscrew the bolts, insert the AC input wires according to polarities indicated on the terminal block and tighten the terminal screws.

Step 1




Note:

Cable suggestion: Cross-section 8-10AWG.



Earth cable PE suggestion: Cross-section (Copper) 8-10AWG


Note:

The Max. power load connects to EPS port should not exceed the inverter's EPS Max. output power range.

Step 2

Step 3


Insert the connector into the inverter, if hear a "click", it means the connection is finished.


Step 4

Warning:

Special tools are required when disassembling terminals, and manual disassembly is not possible.

4.3.4 DRM

The inverter provides a terminal block for connecting to a demand response enabling device (DRED). The DRED asserts demand response modes (DRMs). The inverter detects and initiates a response to all supported demand response commands within 2s. The inverter only supports DRM0 : The inverter is in the state of "Turn off".



4.3.5 CT or Meter Connection

Meter and a current sensor (CT for short below) are used to detect current power direction of the local load and the grid. The output control function of the inverters will be activated based on the detected data.



Meter


Model : DTSU666
Manufacturer : CHNT
Rated power : 130KW

CT




Model : BH-0.66
Manufacturer : CHNT


Meter



Meter+CT



Install Dual Meters




4.4 Communication Connection

The monitoring module could transmit the data to the cloud server, and display the data on the PC, tablet and smart-phone.


Install the WIFI / Ethernet / GPRS / RS485 Communication

WIFI / Ethernet / GPRS / RS485 communication is applicable to the inverter. Please refer to "Communication Configuration Instruction" for detailed instruction.

Step 1




Step 2



4.5 Earth Connection


**Note:**

A second protective earth (PE) terminal should be connected to the inverter. This prevents electric shock if the original protective PE wire fails.

Step 1**Note:**

Earth cable PE suggestion:
Cross-section (Copper) 6-8 AWG

Step 2



Fix the grounding screw to the grounding connection of the machine housing.




Note:

Make sure the earth cables on the inverter and solar panel frame are separately.

5. Operation

5.1 Control Panel



No.	Items	No.	Items
1	LCD Display	5	UP Touch Button
2	POWER LED Indicator	6	DOWN Touch Button
3	GRID LED Indicator	7	BACK Touch Button
4	FAULT LED Indicator	8	ENTER Touch Button



Note:

Hold UP/DOWN button can be rolling quickly.

Sign	Power	Color	Explanation
POWER	ON	Green	The inverter is stand-by
	OFF		The inverter is power off
GRID	ON	Green	The inverter is feeding power
	OFF		The inverter is not feeding power
FAULT	ON	Red	Fault occurred
	OFF		No fault

5.2 Menu Overview

AF-TH hybrid inverter has a LCD for clearly operating, and menu of the LCD can be presented as following:



5.3 Inverter Setting


The setting is for AF-TH Hybrid inverter. Any doubts, please contact distributor for more details.




Note:

Password **** is divided into two passwords: parameter viewing and modifying parameters. When you need to view the parameters, please enter the password 0000. You need to modify the parameters, please contact the manufacturer.

5.3.1 Time & Date




5.3.2 Safety


**Note:**

For compliance to AS/NZS 4777.2:2020, please select Region from Australia A, B, C or New Zealand. Please contact your local grid operator on which Region to select.


5.3.3 Lithium Battery




5.3.4 PV Mode



5.3.5 Lead Acid



5.3.6 Energy Management System (EMS Param)




Note:

For detailed introduction of each mode, please refer to chapter 3.2 of the user manual.

1. Self-Use
2. Back-Up
3. Selling First
4. Maintain (In development)
5. Command charge and discharge
6. External EMS dispatch


5.3.7 Time of Use




Note:


Timed charge and discharge need to complete the three settings of "Chg Cmd", "Chg Pwr" and "Chg Range", otherwise it will not work properly.

5.3.8 AC Charging




5.3.9 Forced Charging






5.3.10 Forced Discharging



Note:

Forced discharging can be set to three time periods.

5.3.11 Protection Parameters




Note:


When modifying parameters, you need to pay attention to the unit.

5.3.12 Multi-machine in Parallel






5.3.13 DRM Setting (DRMS)



5.3.14 Ground detection


Note:

This inverter complies with IEC 62109-2 clause 13.9 for earth fault alarm monitoring.


If an Earth Fault Alarm occurs, the fault code “J 04” will be displayed on the inverter screen / the LED indicator “Alarm” will light up.


Note:

The product is to be installed in a high traffic area where the fault is likely to be seen.

5.3.15 Enable Power Quality Response Modes

a. Active Power Control Power Factor



Q(P) Set

P1:	50.0%
Q1:	0.0%
P2:	100.0%
Q2:	-44.0%
P3:	100.0%
Q3:	-44.0%
P4:	100.0%
Q4:	-44.0%

Q(P) Set

P1:	50.0%
Q1:	0.0%
P2:	100.0%
Q2:	-44.0%
P3:	100.0%
Q3:	-44.0%
P4:	100.0%
Q4:	-44.0%





→ P:Rated active power percentage
Q:Rated reactive power percentage



Note:

When Q(P) Set is set, Power Quality Response Mode is enabled




b. Voltage Control Reactive Power

Note:

When Q(V) Set is set, Power Quality Response Mode is enabled


Note:

Volt-var is enabled by default.

c. Fixed Power Factor





Note:

Set PF (-0.8, +0.8), Resolution 0.001.

When PF Set is set, Power Quality Response Mode is enabled


d. Fixed Reactive Power (%)




Note:

When PF(P) Set is set, Power Quality Response Mode is enabled


5.3.16 Disable Power Quality Response Modes


Note:


When OFF is set, Power Quality Response Modes is disabled.

5.3.17 Active Power Mode Set

a. Active Power Percentages



b. Volt-watt



V1:	100.0%
P1:	100.0%
V2:	100.0%
P2:	100.0%
V3:	110.0%
P3:	100.0%
V4:	113.0%
P4:	20.0%

V1:	100.0%
P1:	100.0%
V2:	100.0%
P2:	100.0%
V3:	110.0%
P3:	100.0%
V4:	113.0%
P4:	20.0%



→ P: Rated active power percentage
V: Percentage of rated voltage


Note:


The volt-watt response mode shall be enabled by default.



Note:

When charging, the software has set the parameters by default.




5.3.18 Frequency protection range (Freq Range) Setting







5.3.19 Voltage protection range (Volt Range) set



5.3.20 Version



5.3.21 Install Dual Meters



5.3.22 Active anti-islanding protection

The method of active anti-islanding protection:

Shifting the frequency of the inverter away from nominal conditions in the absence of a reference frequency (frequency shift).

6. Power ON/OFF

Please check the following requirements before testing:

- Installation location is suitable according to Chapter 4.1.3.
- All electrical wires are connected tightly, including PV modules, battery and AC side(Such as the grid side, EPS side, Gen side).
- Earth line and Smart meter/CT line are connected.
- AF-TH hybrid inverters should be set according to the required local grid standard.
- More information please contact with Afore or distributors.


6.1 Power ON

- Connection Sequence:
PV Breaker → Battery Breaker → Off-grid Breaker → AC Grid Breaker.
- After LCD lighting, hybrid inverter should be set following Chapter 5.3 at the first time.
- When inverter running under normal mode, Running indicator will light up(Ref. to Chapter 5.1).

6.2 Power OFF

- Disconnection Sequence:
AC Grid Breaker → Off-grid Breaker → Battery Breaker → PV Breaker

Note: Before maintenance, ensure the DC switch is turned off and locked.



Note:

Hybrid inverter should be restarted after 5 minutes.

6.3 Restart

Restart Hybrid inverter, please follow steps as below:

- Shutdown the inverter Ref. to Chapter 6.2.
- Start the inverter Ref. to Chapter 6.1.

7. Maintenance & Trouble Shooting

7.1 Maintenance

Periodically maintenance are necessary, please follow steps as below.

- Be sure to use special insulation tools when perform high-voltage operations.
- Before any service work, first disconnect the grid-side AC circuit breaker and check the inverter status. If the inverter indicator is off, please wait until night to disconnect the DC switch. If the inverter indicator is on, directly disconnect and lock the DC switch (For lockout procedures, see Section 6.2.).
- After the inverter is powered off for 5 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.
- Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.
- When maintaining the product, it is strictly prohibited to open the product if there is an odor or smoke or if the product appearance is abnormal. If there is no odor, smoke, or obvious abnormal appearance, repair or restart the inverter according to the alarm corrective measures. Avoid standing directly in front of the inverter during maintenance.

Safety:

- Before maintenance, disconnect the AC circuit breaker on the grid side and then the DC switch. If a fault that may cause personal injury or device damage is found before maintenance, disconnect the AC circuit breaker and wait until the night before operating the DC switch. Otherwise, a fire inside the product or an explosion may occur, causing personal injuries.
- After the inverter is powered off for 5 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.
- Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.
- Touching the power grid or the contact points and terminals on the inverter connected to the power grid may lead to electric shock! The power grid side may generate voltage. Always use a standard voltmeter to ensure that there is no voltage before touching.

7.2 Trouble Shooting

The fault messages are displayed when fault occurs, please check trouble shooting table and find related solutions.

Fault Code and Trouble Shooting

Type of Fault	Code	Name	Description	Recommend Solution
PV Fault	A01	PvConnectFault	PV connection type different from setup	• Check PV modules connection • Check PV Mode setup Ref. Chapter 5.3.
	A02	IsoFault	ISO check among PV panels/ wires and ground is abnormal.	• Check PV modules wires, those wires are soaked or damaged, and then carry out rectification. • if the fault occurs continuously and frequently, please ask help for local distributors.
	A03	PvAfcFault	PV current arcing	• Check PV modules wires and connectors broken or loose connect, and then carry out rectification. • If the fault occurs continuously and frequently, please ask help for local distributors.
	A04	Pv1OverVoltFault	PV Voltage over	• Reconfiguration of PV strings, reduce the PV number of a PV string to reducing inverter PV input voltage. • Suggestion that contacting with local distributors.
	A05	Pv2OverVoltFault		
	A06	Pv3OverVoltFault		
	A07	Pv4OverVoltFault		
	A08	Pv5OverVoltFault		
	A09	Pv6OverVoltFault		
	A10	Pv7OverVoltFault		
	A11	Pv8OverVoltFault		
	A12	Pv9OverVoltFault		
	A13	Pv10OverVoltFault		
	A14	Pv11OverVoltFault		
	A15	Pv12OverVoltFault		
	A16	PV1ReverseFault	PV(+) and PV(-) reversed Connection	• Check PV(+) and PV(-) Connect whether reversed or not. • If reversed, make correction.
	A17	PV2ReverseFault		
	A18	PV3ReverseFault		
	A19	PV4ReverseFault		
	A20	PV5ReverseFault		
	A21	PV6ReverseFault		

Type of Fault	Code	Name	Description	Recommend Solution
PV Fault	A22	PV7ReverseFault		
	A23	PV8ReverseFault		
	A24	PV9ReverseFault		
	A25	PV10ReverseFault		
	A26	PV11ReverseFault		
	A27	PV12ReverseFault		
	A33	Pv1AbnormalFault	PV(+) and PV(-) reversed Connection	• Check PV modules partial occlusion or cells damaged. • Check PV module wires and connectors broken or loose connect, then repair it.
	A34	Pv2AbnormalFault		
	A35	Pv3AbnormalFault		
	A36	Pv4AbnormalFault		
	A37	Pv5AbnormalFault		
	A38	Pv6AbnormalFault		
	A39	Pv7AbnormalFault		
	A40	Pv8AbnormalFault		
	A41	Pv9AbnormalFault		
	A42	Pv10AbnormalFault		
	A43	Pv11AbnormalFault		
	A44	Pv12AbnormalFault		
	A45	Pv13AbnormalFault		
	A46	Pv14AbnormalFault		
	A47	Pv15AbnormalFault		
	A48	Pv16AbnormalFault		
	A49	Pv17AbnormalFault		
	A50	Pv18AbnormalFault		
	A51	Pv19AbnormalFault		
	A52	Pv20AbnormalFault		
	A53	Pv21AbnormalFault		
	A54	Pv22AbnormalFault		
	A55	Pv23AbnormalFault		
	A56	Pv24AbnormalFault		

Type of Fault	Code	Name	Description	Recommend Solution
Battery Fault	B01	PcsBatOverVoltFault	Battery voltage over or under	• Check inverters connected battery lines and connectors broken or loose connect. • Carry out rectification if broken or loose. • Checking battery voltage is abnormal or not, then maintenance or change new battery.
	B02	PcsBatUnderVoltFault		
	B03	PcsBatInsOverVoltFaul		
	B04	PcsBatReversedFault	Bat. (+) and Bat. (-) are reversed.	• Check Bat.(+) and Bat.(-)connect reversed or not. • Make correction If reversed.
	B05	PcsBatConnectFault	Battery wires loose	• Check battery wires and connectors damage or loose connect. • Carry out rectification if break.
	B06	PcsBatComFault	Battery communication abnormal	• Check battery side communication wires damage or loose connect, and then carry out rectification. • Check battery is off or other abnormal, then Mastertenance battery or change new battery.
	B07	PcsBatTempSensorOpen	Battery temperature sensor abnormal	• Check battery temperature sensor and connected wires damage or not , then rectification or change new one.
	B08	PcsBatTempSensorShort		
	B09	BmsBatSystemFault	All these faults will be detected or reported by battery BMS.	• If specific fault high temperature or low temperature, then should change battery installed environment temperature. • Restart battery, maybe can working as normal. • If this fault occurs continuously and frequently, please ask help for local distributors.
	B10	BmsBatVolOverFault		
	B11	BmsBatVolUnderFault		
	B12	BmsCellVolOverFault		
	B13	BmsCellVolUnderFault		
	B14	BmsCellVolUnbanceFau		
	B15	BatChgCurOverFault		
	B16	BatDChgCurOverFault		
	B17	BatTemperatureOverFa		
	B18	BatTemperatureUnderF		
	B19	CelTemperatureOverFa		
	B20	CelTemperatureUnderF		
	B21	BatIsoFault		
	B22	BatSocLowFault		
	B23	BmsInterComFault		
	B24	BatRelayFault		

Type of Fault	Code	Name	Description	Recommend Solution
Battery Fault	B25	BatPreChaFault		
	B26	BmsBatChgMosFault		
	B27	BmsBatDChgMosFault		
	B28	BMSVolOVFault		
	B29	BMSVolLFault		
	B30	VolLockOpenFault		
	B31	VolLockShortFault		
	B32	ChgRefOVFault		
	C01	GridLossFault	Grid lost (islanding)	• Inverter will restart automatically when the grid return to normal. • Check inverter connected with grid connectors and cable normal or not.
	C02	GridUnbalanVoltFault	Grid Voltage unbalanced.	• The inverter will restart automatically when the grid three phase return to normal. • Check inverter connected with the grid connectors and wires normal or not. connectors and cable normal or not.
	C03	GridInstOverVoltFault	Grid instantaneous voltage over	• The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust protection parameters.
	C04	Grid10MinOverVoltFault	Grid voltage Over by 10 Minutes	• The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust 10 minutes protection voltage parameters.
	C05	GridOverVoltFault	Grid voltage over	• The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust voltage protection parameters.
	C06	GridUnderVoltFault	Grid voltage under	
	C07	GridLineOverVoltFault	Grid line voltage over	
	C08	GridLineUnderVoltFault	Grid line voltage under	
	C09	GridOverFreqFault	Grid Frequency over	• The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust frequency protection parameters.
	C10	GridUnderFreqFault	Grid Frequency under	

Type of Fault	Code	Name	Description	Recommend Solution
Off-grid Fault	D01	UpsOverPowerFault	Off-grid load over	• Reduce loads. • If sometimes overload, it can be ignored, when generation power enough can be recovery. • If those faults occurs continuously and frequently, please ask help for local distributors.
	D02	GridConflictFault	Grid connected to Back-up terminal	• Check the off-grid port connection correct, disconnect both off-grid and grid ports.
	D03	GenOverVoltFault	GenOverVoltFault	• Adjust generator running parameters, make the output voltage, frequency in allowed range. • If this fault occurs continuously and frequently, please ask help for local distributors.
	D04	GenUnderVoltFault	GenUnderVoltFault	
	D05	GenOverFreqFault	GenOverFreqFault	
	D06	GenUnderFreqFault	GenUnderFreqFault	
DC Fault	E01	Pv1HwOverCurrFault	PV current over, triggered by hardware protection circuit	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	E02	Pv2HwOverCurrFault		
	E03	Pv3HwOverCurrFault		
	E04	Pv4HwOverCurrFault		
	E05	Pv5HwOverCurrFault		
	E06	Pv6HwOverCurrFault		
	E07	Pv7HwOverCurrFault		
	E08	Pv8HwOverCurrFault		
	E09	Pv9HwOverCurrFault		
	E10	Pv10HwOverCurrFault		
	E11	Pv11HwOverCurrFault		
	E12	Pv12HwOverCurrFault		
	E13	Pv1SwOverCurrFault	PV current over, triggered by Software logic.	• Power off, power on then restart. • If those faults occurs continuously and frequently, please ask help for local distributors.
	E14	Pv2SwOverCurrFault		
	E15	Pv3SwOverCurrFault		
	E16	Pv4SwOverCurrFault		
	E17	Pv5SwOverCurrFault		
	E18	Pv6SwOverCurrFault		
	E19	Pv7SwOverCurrFault		
	E20	Pv8SwOverCurrFault		

Type of Fault	Code	Name	Description	Recommend Solution
DC Fault	E21	Pv9SwOverCurrFault		
	E22	Pv10SwOverCurrFault		
	E23	Pv11SwOverCurrFault		
	E24	Pv12SwOverCurrFault		
	E33	Boost1SelfCheck(boost)Fault	PV boost circuit abnormal when self checking	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E34	Boost2SelfCheck(boost)Fault		
	E35	Boost3SelfCheck(boost)Fault		
	E36	Boost4SelfCheck(boost)Fault		
	E37	Boost5SelfCheck(boost)Fault		
	E38	Boost6SelfCheck(boost)Fault		
	E39	Boost7SelfCheck(boost)Fault		
	E40	Boost8SelfCheck(boost)Fault		
	E41	Boost9SelfCheck(boost)Fault		
	E42	Boost10SelfCheck(boost)Fault		
	E43	Boost11SelfCheck(boost)Fault		
	E44	Boost12SelfCheck(boost)Fault		
	E45	BusHwOverVoltFault	Bus voltage over	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E46	BusHwOverHalfVoltFault		
	E47	BusSwOverVoltFault		
	E48	BusSwOverHalfVoltFault		
	E49	BusSwUnderVoltFault	Bus voltage under as running	
	E50	BusUnbalancedFault	DC Bus voltage unbalanced	
	E51	BusBalBridgeHwOver-CurFault	Bus Controller current over	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E52	BusBalBridgeSwOver-CurFault		
	E53	BusBalBridgeSelf-CheckFault	Bus Controller abnormal when self checking	
	E54	BDCHwOverCurrFault	BiDC current over	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E55	BDCSwOverCurrFault		
	E56	BDCSelfCheckFault	BiDC abnormal as self checking	
	E57	BDCSwOverVoltFault	BiDC voltage over	
	E58	TransHwOverCurrFault	BiDC current over	

Type of Fault	Code	Name	Description	Recommend Solution
	E59	BDCFuseFault	BiDC fuse broken	• Change fuse.
	E60	BDCRelayFault	BiDC relay abnormal	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
AC Fault	F01	HwOverFault	All over current/ voltage by protection hardware	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	F02	InvHwOverCurrFault	Ac over current by protection hardware	
	F03	InvROverCurrFault	R phase current over	
	F04	InvSOverCurrFault	S phase current over	
	F05	InvTOverCurrFault	T phase current over	
	F06	GridUnbalanCurrFault	On-grid current unbalanced	
	F07	DclnjOverCurrFault	DC injection current over	
	F08	AcOverLeakCurrFault	Ac side leakage current over	• Check AC insulation and ground wires connect ground is well or not, then repair it. • Power off, then restart (Ref. Chapter8).. • If those fault occurs continuously and frequently, please ask help for local distributors.
	F09	PLLFault	PLL abnormal	• Power off, then restart (Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F10	GridRelayFault	Grid relay abnormal	
	F11	UpsRelayFault	Ups relay abnormal	
	F12	GenRelayFault	Generator relay abnormal	
	F13	Relay4Fault	Relay4 abnormal	
	F14	UpsROverCurrFault	Off-grid output current over	• When off-grid the load start impulse current is over, reduce the start impulse current load. • Power off, then restart (Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F15	UpsSOverCurrFault		
	F16	UpsTOverCurrFault		
	F17	GenROverCurrFault	Generator current over	• Check generator output voltage, frequency is stability, and adjust generator. • Power off, then restart(Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F18	GenSOverCurrFault		
	F19	GenTOverCurrFault		
	F20	GenReversePowerFault	Active power injected to generator	

Type of Fault	Code	Name	Description	Recommend Solution
AC Fault	F21	UpsOverVoltFault	Off-grid output voltage over or under	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	F22	UpsUnderVoltFault		
	F23	UpsOverFreqFault	Off-grid output frequency over or under	
	F24	UpsUnderFreqFault		
	F25	DcInjOverVoltFault	Off-grid DC injection voltage over	
System Fault	G01	PV1CurAdChanFault	Sampling hardware abnormal	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	G02	PV2CurAdChanFault		
	G03	PV3CurAdChanFault		
	G04	PV4CurAdChanFault		
	G05	PV5CurAdChanFault		
	G06	PV6CurAdChanFault		
	G07	PV7CurAdChanFault		
	G08	PV8CurAdChanFault		
	G09	PV9CurAdChanFault		
	G10	PV10CurAdChanFault		
	G11	PV11CurAdChanFault		
	G12	PV12CurAdChanFault		
	G13	BDCCurrAdChanFault		
	G14	TransCurAdChanFault		
	G15	BalBrigCurAdChanFault		
	G16	RInvCurAdChanFault		
	G17	SInvCurAdChanFault		
	G18	TInvCurAdChanFault		
	G19	RInvDciAdChanFault		
	G20	SInvDciAdChanFault		
	G21	TInvDciAdChanFault		
	G22	LeakCurAdChanFault		
	G23	VoltRefAdChanFault		
	G24	UpsRCurAdChanFault		

Type of Fault	Code	Name	Description	Recommend Solution
System Fault	G25	UpsSCurAdChanFault		
	G26	UpsTCurAdChanFault		
	G27	GenRCurAdChanFault		
	G28	GenSCurAdChanFault		
	G29	GenTCurAdChanFault		
	G30	UpsRDcvAdChanFault		
	G31	UpsSDcvAdChanFault		
	G32	UpsTDcvAdChanFault		
	G37	TempAdChanFault	All temperature sensors abnormal	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	G38	VoltAdConflictFault	The sample value of PV, battery and BUS voltage inconsistent	
	G39	CPUAdConflictFault	The sample value between master CPU and slaver CPU inconsistent	
	G40	PowerCalcConflictFault	Power value between PV, battery and AC output inconsistent	
	G41	EnvirOverTempFault	Installation environment temperature over or low	• Change or improve the installation environment temperature, make running temperature suitable. • Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	G42	EnvirLowTempFault		
	G43	CoolingOverTempFault	Cooling temperature over or low	
	G44	CoolingLowTempFault		
	G45	OverTemp3Fault	Temperature3 over or low	
	G46	LowTemp3Fault		
	G47	CpuOverTempFault	CPU temperature over	
G48	ModelConflictFault	Version conflict with inverter	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.	
Inner Warning	I01	InterFanWarning	Fan abnormal	• Remove foreign matter logged in fan. • If those faults occurs continuously and frequently, please ask help for local distributors.
	I02	ExterFanWarning		
	I03	Fan3Warning		

Type of Fault	Code	Name	Description	Recommend Solution
Inner Warning	I04	EnvirTempAdChan-Warning	Some temperature sensors abnormal	- The warnings are not matter influence. - Power off, then restart (Ref. Chapter8). - If those faults occurs continuously and frequently, please ask help for local distributors.
	I05	CoolingTempAdChan-Warning		
	I06	Temp3AdChanWarning		
	I07	ExtFlashComWarning	Flash abnormal	- Power off, then restart (Ref. Chapter8). - If this those faults continuously and frequently, please ask help for local distributors.
	I08	EepromComWarning	Eeprom abnormal	
	I09	SlaveComWarning	Communication between slaver CPU and master CPU abnormal	
	I10	HmiComWarning	HMI abnormal	
	I11	FreqCalcConflictWarning	Frequency value abnormal	
	I12	UnsetModel	Running model is not initial	Contact with local distributor.
Outside Warning	J01	MeterComWarning	Meter/CT abnormal	- Check the smart meter model, connection or connectors are correct, any loose. - if abnormal, repair or change. - Power off, then restart (Ref. Chapter8). - If those faults occurs continuously and frequently, please ask help for local distributors.
	J02	MeterConnectWarning	Wires connecting type of meter wrong	- Check Meter/CT connection, installed place, and installed direction. - if abnormal, re-installation. - Power off, then restart (Ref. Chapter8). - If this those faults continuously and frequently, please ask help for local distributors.
	J03	SohWarning	Battery SOH low	Contact with Battery manufacturer.
	J04	GndAbnormalWarning	Earth impedance over by cable loose and so on	- Check earth line connection or earth connecting impedance. - if abnormal, then adjust it. - Power off, then restart (Ref. Chapter8). - If this those faults continuously and frequently, please ask help for local distributors.
	J05	ParallelComWarning	Communication between master inverter and slaver ones abnormal in parallel mode	- Check parallel connect communication wires damage, connectors loose, connect port correct or not. - if not, then adjust it. - Power off, then restart (Ref. Chapter8). - If this those faults continuously and frequently, please ask help for local distributors.

PV Input	AF3K-TH	AF4K-TH	AF5K-TH	AF6K-TH	AF8K-TH	AF10K-TH
Max. Input Power (kW)	5	6	7.5	9	12	15
Max. PV Voltage (V)	1000					
MPPT Range (V)	150 - 850					
Full MPPT Range (V)	200-850		250 - 850		300 - 850	500 - 850
Min. Operating Voltage (Vdc)	160					
Startup Voltage (V)	160					
Max. Input Current (A)	20 x 2					
Max. Short Current (A)	30 x 2					
Back feed current (A)	0					
No. of MPP Tracker / No. of PV String	2 / 2					
Battery Port						
Max. Charge/Discharge Power (kW)	3.0	4.0	5.0	6.0	8.0	10
Max. Charge/Discharge Current (A)	30					
Battery Normal Voltage (V)	200					
Battery Voltage Range (V)	150-800					
Battery Type	Li-ion / Lead-acid					
AC Grid						
Max Continuous Current (A)	5.3	7.0	8.5	10.5	13.5	17.0
Max Continuous Power (kVA)	4.5	6.0	7.5	9.0	12.0	15.0
Nominal Grid Current (A)	4.4	5.8	7.3	8.7	11.6	14.5
Max. Output Over Current Protection (A)	5.3	7.0	8.5	10.5	13.5	17.0
Inrush Current (peak and duration) (A)	7.5A@50us	9.9A@50us	12.1A@50us	14.9A@50us	19.1A@50us	24.1A@50us
Max. Fault Current (peak and duration) (A)	10A@10us	13.5A@10us	16.5A@10us	20A@10us	26.5A@10us	33A@10us
Rated Power (kW)	3.0	4.0	5.0	6.0	8.0	10.0
Rated Apparent Power (kVA)	3.0	4.0	5.0	6.0	8.0	10.0
Nominal Grid Voltage (V)	3P+N+PE/3P+PE 230/400					
Nominal Grid Frequency (Hz)	50					
Power Factor	1.0 (-0.8~+0.8 adjustable)					
Current THD (%)	< 3					
AC Back-up						
Max Continuous Current (A)	5.3	7.0	8.5	10.5	13.5	17.0
Max Continuous Power (kVA)	4.5	6.0	7.5	9.0	12.0	15.0
Rated Apparent Power (kVA)	4.5	6.0	7.5	9.0	12.0	15.0
Max Peak Power (kVA) (1min)	3.3	4.4	5.5	6.6	8.8	11.0
Nominal AC Current (A)	4.4	5.8	7.3	8.7	11.6	14.5
Max. Output Over Current Protection (A)	5.3	7.0	8.5	10.5	13.5	17.0
Inrush Current (peak and duration) (A)	7.5A@50us	9.9A@50us	12.1A@50us	14.9A@50us	19.1A@50us	24.1A@50us
Max. Fault Current (peak and duration) (A)	10A@10us	13.5A@10us	16.5A@10us	20A@10us	26.5A@10us	33A@10us
Nominal AC Voltage L-N (V)	3P+N+PE/3P+PE 230/400					
Nominal AC Frequency (Hz)	60					
Switching Time (s)	Seamless					
Voltage THD (%)	< 3					
Efficiency						
CEC Efficiency (%)	97.5					
Max. Efficiency (%)	98.0				98.2	
Protection						
PV Reverse Polarity Protection	Yes					
Over Current/Voltage Protection	Yes					
Anti-Islanding Protection	Yes					
AC Short Circuit Protection	Yes					
Residual Current Detection	Yes					
Ground Fault Monitoring	Yes					
Insulation Resister Detection	Yes					
PV Arc Detection	Yes					
Enclosure Protect Level	IP65					
General Data						
Dimensions (W x H x D, mm)	558*535*260					
Weight (kg)	20				22	
Topology	Transformerless					
Cooling	Natural Cooling				Smart cooling	
Relatively Humidity	0 - 100 %					
Overvoltage category	OVC III (AC Main), OVC II (PV)					
Inverter Isolation	Non-isolated(PV-AC-BAT)					
Operating Temperature Range	-25 ~ +60°C (Derating 45°C)					
Operating Altitude (m)	2000					
Noise Emission (dB)	< 30					
Standby Consumption (W)	< 5					
Mounting	Wall Bracket					
Communication with RSD	SUNSPEC					
Display & Communication Interfaces	LCD, LED, RS485, CAN, Wi-Fi, GPRS, 4G					
Certification & Approvals	NR597, G98/G99, EN50549-1, C10/C11, AS 4777.2, VDE-AR-N4105, VDE0126, IEC62040, IEC62109-1, IEC62109-2					
EMC	EN61000-6-1, EN61000-6-3					
DRM0	DRM1	DRM2	DRM3	DRM4	DRM5	DRM6
DRM7	DRM8	DRM9	DRM10	DRM11	DRM12	DRM13

PV Input	AF12K-TH	AF15K-TH	AF17K-TH	AF20K-TH	AF25K-TH	AF30K-TH
Max. Input Power (kW)	18.0	22.5	25.5	30.0	37.5	45.0
Max. PV Voltage (V)	1000					
MPPT Range (V)	150 - 850					
Full MPPT Range (V)	500 - 850					
Min. Operating Voltage (Vdc)	160					
Startup Voltage (V)	160					
Max. Input Current (A)	20 x 2	20 + 32	32 x 2	40 x 2		
Max. Short Current (A)	30 x 2	30 + 48	48 x 2	60 x 2		
Back feed current (A)	0					
No. of MPP Tracker / No. of PV String	2 / 2	2 / 3	2 / 4	2 / 4		
Battery Port						
Max. Charge/Discharge Power (kW)	12.0	15.0	17.0	20.0	25.0	30.0
Max. Charge/Discharge Current (A)	30	50	50	50	60	60
Battery Normal Voltage (V)	450	500	400	500	500	550
Battery Voltage Range (V)	40 - 60					
Battery Type	Li-ion / Lead-acid					
AC Grid						
Max Continuous Current (A)	21.5	27.0	30.0	32.0	40.0	48.0
Max Continuous Power (kVA)	18.0	22.5	25.5	30.0	37.5	45
Nominal Grid Current (A)	17.4	21.8	24.7	29.0	36.3	43.5
Max. Output Over Current Protection (A)	21.5	27.0	30.0	32.0	40.0	48.0
Inrush Current (peak and duration) (A)	30.5A@50us	38.2A@50us	42.5A@50us	45.3A@50us	56.6A@50us	67.9A@50us
Max. Fault Current (peak and duration) (A)	39.5A@10us	49.5A@10us	56A@10us	65.5A@10us	82A@10us	98A@10us
Rated Power (kW)	12.0	15.0	18.0	20.0	25.0	30.0
Rated Apparent Power (kVA)	12.0	15.0	18.0	20.0	25.0	30.0
Nominal Grid Voltage (V)	3P+N+PE/3P+PE 230/400					
Nominal Grid Frequency (Hz)	50					
Power Factor	1.0 (-0.8~+0.8 adjustable)					
Current THD (%)	< 3					
AC Back-up						
Max Continuous Current (A)	21.5	27.0	30.0	32.0	40.0	48.0
Max Continuous Power (kVA)	12.0	15.0	18.0	20.0	25.0	30.0
Rated Apparent Power (kVA)	12.0	15.0	18.0	20.0	25.0	30.0
Max Peak Power (kVA) (1min)	13.2	16.5	18.7	22.0	27.5	33.0
Nominal AC Current (A)	17.4	21.8	24.8	29.0	36.3	43.5
Max. Output Over Current Protection (A)	21.5	27.0	30.0	32.0	40.0	48.0
Inrush Current (peak and duration) (A)	30.5A@50us	38.2A@50us	42.5A@50us	45.3A@50us	56.6A@50us	67.9A@50us
Max. Fault Current (peak and duration) (A)	39.5A@10us	49.5A@10us	56A@10us	65.5A@10us	82A@10us	98A@10us
Nominal AC Voltage L-N (V)	3P+N+PE/3P+PE 230/400					
Nominal AC Frequency (Hz)	50					
Switching Time (s)	Seamless					
Voltage THD (%)	< 3					
Efficiency						
CEC Efficiency (%)	97.5		97.8		98.0	98.1
Max. Efficiency (%)	98.3		98.5			
Protection						
PV Reverse Polarity Protection	Yes					
Over Current/Voltage Protection	Yes					
Anti-Islanding Protection	Yes					
AC Short Circuit Protection	Yes					
Residual Current Detection	Yes					
Ground Fault Monitoring	Yes					
Insulation Resister Detection	Yes					
PV Arc Detection	Yes					
Enclosure Protect Level	IP65					
General Data						
Dimensions (W x H x D, mm)	558 x 535 x 260					
Weight (kg)	29				36	
Topology	Transformerless					
Cooling	Intelligent Fan					
Relatively Humidity	0 - 100 %					
Overvoltage category	OVC III (AC Main), OVC II (PV)					
Inverter Isolation	Non-isolated(PV-AC-BAT)					
Operating Temperature Range	-25 ~ +60°C (Derating 45°C)					
Operating Altitude (m)	2000					
Noise Emission (dB)	< 30	< 40				
Standby Consumption (W)	< 5					
Mounting	Wall Bracket					
Communication with RSD	SUNSPEC					
Display & Communication Interfaces	LCD, LED, RS485, CAN, Wi-Fi, GPRS, 4G					
Certification & Approvals	NR597, G98/G99, EN50549-1, C10/C11, AS 4777.2, VDE-AR-N4105, VDE0126, IEC62040, IEC62109-1, IEC62109-2					
EMC	FN61000-6-1 FN61000-6-3					

DRM0



DRM1



DRM2



DRM3



DRM4



DRM5



DRM6



DRM7



DRM8

