ATTESTATION OF CONFORMITY

Issued to:	Afore New Energy Technology (Shanghai) Co., Ltd. Build No.7, 333 Wanfang Road, Minhang District, Shanghai, China
For the product:	On-Grid PV Inverter
Trade name:	Afore
Type/Model:	BNT003KTL, BNT004KTL, BNT005KTL, BNT006KTL, BNT008KTL BNT010KTL
Ratings:	See Annex
Manufactured by:	Afore New Energy Technology (Shanghai) Co., Ltd. Build No.7, 333 Wanfang Road, Minhang District, Shanghai, China
Requirements:	Engineering Recommendation G98 Issue 1 – Amendment 7: 2022

This Attestation is granted on account of an examination by DEKRA, the results of which are laid down in a confidential file no. 6136782.52

The examination has been carried out on one single specimen or several specimens of the product, submitted by the manufacturer. The Attestation does not include an assessment of the manufacturer's production. Conformity of his production with the specimen tested by DEKRA is not the responsibility of DEKRA.

Arnhem, 8 June 2023 Number: 6136782.03AOC

DEKRA Testing and Certification (Shanghai) Ltd.

Kreny Lin
Certification Manager

DEKRA Testing and Certification (Shanghai) Ltd.
3F #250 Jiangchangsan Road Shibei Hi-Tech Park, 200436 Jing'an District, Shanghai, China
T +86 21 6056 7666 F +86 21 6056 7555 www.dekra-product-safety.com

Ratings of the test product:
Operating temperature range: - 25°C to + 60°C
Protective class: I
Ingress protection rating: IP65
Power factor range (adjustable): 0.8 leading…0.8 lagging

BNT003KTL:
PV input: Max. 1100 Vdc, MPPT voltage range: 150-1000 Vdc, max 15*2 A, Isc PV: 25*2 A
AC Output: 3P+N+PE/ 3P+PE, 230/ 400 Vac, 50/ 60 Hz, Nominal 3000 VA, rated 4.4 A, max 5.3 A

BNT004KTL:
PV input: Max. 1100 Vdc, MPPT voltage range: 150-1000 Vdc, max 15*2 A, Isc PV: 25*2 A
AC Output: 3P+N+PE/ 3P+PE, 230/ 400 Vac, 50/ 60 Hz, Nominal 4000 VA, rated 5.8 A, max 7.0 A

BNT005KTL:
PV input: Max. 1100 Vdc, MPPT voltage range: 150-1000 Vdc, max 15*2 A, Isc PV: 25*2 A
AC Output: 3P+N+PE/ 3P+PE, 230/ 400 Vac, 50/ 60 Hz, Nominal 5000 VA, rated 7.3 A, max 8.5 A

BNT006KTL:
PV input: Max. 1100 Vdc, MPPT voltage range: 150-1000 Vdc, max 15*2 A, Isc PV: 25*2 A
AC Output: 3P+N+PE/ 3P+PE, 230/ 400 Vac, 50/ 60 Hz, Nominal 6000 VA, rated 8.7 A, max 10.5 A

BNT008KTL:
PV input: Max. 1100 Vdc, MPPT voltage range: 150-1000 Vdc, max 15*2 A, Isc PV: 25*2 A
AC Output: 3P+N+PE/ 3P+PE, 230/ 400 Vac, 50/ 60 Hz, Nominal 8000 VA, rated 11.6 A, max 13.5 A

BNT010KTL:
PV input: Max. 1100 Vdc, MPPT voltage range: 150-1000 Vdc, max 15*2 A, Isc PV: 25*2 A
AC Output: 3P+N+PE/ 3P+PE, 230/ 400 Vac, 50/ 60 Hz, Nominal 10000 VA, rated 14.5 A, max 17.0 A

G98/1-7 Form C: Type Test Verification Report	
Extract form test report number.:	**6136782.52**

1. Operating Range:				**P**
This test should be carried out as specified in A.1.2.10. Pass or failure of the test should be indicated in the fields below (right hand side), for example with the statement “Pass”, “No disconnection occurs”, etc. Graphical evidence is preferred.				
Model: BNT010KTL				
Test 1:				
Measured Voltage (V)	Measured Frequency (Hz)	Measured Power (W)	Measured Power factor	Test Time (seconds)
195.61	47.00	9889.91	0.9994	20
Test 2:				
Measured Voltage (V)	Measured Frequency (Hz)	Measured Power (W)	Measured Power factor	Test Time (Minutes)
195.62	47.50	9886.80	0.9994	90
Test 3:				
Measured Voltage (V)	Measured Frequency (Hz)	Measured Power (W)	Measured Power factor	Test Time (Minutes)
253.04	51.50	10070.87	0.9979	90
Test 4:				
Measured Voltage (V)	Measured Frequency (Hz)	Measured Power (W)	Measured Power factor	Test Time (Minutes)
253.08	52.00	10069.46	0.9979	15
Test 5:				
Measured Voltage (V)	Measured Frequency (Hz)	Measured Power (W)	Measured Power factor	Test Time (Minutes)
230.56	50.00	10075.42	0.9989	90
Test 6:				
Measured Voltage (V)	Ramp range	Test frequency ramp	Test Duration	Confirm no trip
195.5	47.0 Hz to 52.0 Hz	+1 Hzs^{-1}	5.0s	No trip
253.0	52.0 Hz to 49.0 Hz	-1 Hzs^{-1}	3.0s	No trip

2. Power Quality – Harmonics:	**P**

These tests should be carried out as specified in BS EN 61000-3-2. The chosen test should be undertaken with a fixed source of energy at two power levels a) between 45 and 55% and b) at 100% of **Registered Capacity**. The test requirements are specified in Annex A1 A.1.3.1 (**Inverter** connected) or Annex A2 A.2.3.1 (Synchronous).

Model: BNT003KTL

L1

Micro-generator tested to BS EN 61000-3-2

Micro-generator rating per phase (rpp)	1	kW
For 3-phase **Micro-generator**s, tick this box if harmonic measurements are identical for all three phases. If the harmonics are not identical for each phase, please replicate this section with the results for each phase.	three phase PV inverter	

Harmonic	At 45-55% of **Registered Capacity**		100% of **Registered Capacity**			
	Measured Value MV in Amps	Normalised Value (NV) in Amps	Measured Value MV in Amps	Normalised Value (NV) in Amps	Limit in BS EN 61000-3-2 in Amps	Higher limit for odd harmonics 21 and above
2	0.018	0.132	0.026	0.096	1.080	
3	0.070	0.514	0.028	0.103	2.300	
4	0.011	0.077	0.011	0.042	0.430	
5	0.140	1.027	0.120	0.442	1.140	
6	0.008	0.060	0.008	0.030	0.300	
7	0.064	0.474	0.052	0.192	0.770	
8	0.010	0.074	0.006	0.024	0.230	
9	0.028	0.202	0.009	0.033	0.400	
10	0.010	0.074	0.007	0.026	0.184	
11	0.149	0.275	0.024	0.086	0.330	
12	0.013	0.093	0.005	0.020	0.153	
13	0.057	0.140	0.037	0.136	0.210	
14	0.005	0.039	0.006	0.024	0.131	
15	0.019	0.144	0.005	0.020	0.150	
16	0.006	0.047	0.005	0.019	0.115	
17	0.020	0.048	0.032	0.059	0.132	
18	0.007	0.048	0.005	0.019	0.102	
19	0.006	0.043	0.038	0.024	0.118	
20	0.005	0.035	0.006	0.021	0.092	
21	0.011	0.081	0.010	0.038	0.107	0.160
22	0.007	0.051	0.006	0.021	0.084	
23	0.035	0.085	0.039	0.024	0.098	0.147
24	0.006	0.043	0.007	0.024	0.077	
25	0.040	0.060	0.024	0.088	0.090	0.135
26	0.004	0.032	0.006	0.021	0.071	

27	0.008	0.058	0.011	0.041	0.083	0.124
28	0.004	0.032	0.005	0.018	0.066	
29	0.018	0.027	0.023	0.028	0.078	0.117
30	0.005	0.038	0.007	0.025	0.061	
31	0.010	0.040	0.022	0.021	0.073	0.109
32	0.005	0.036	0.005	0.018	0.058	
33	0.004	0.031	0.008	0.029	0.068	0.102
34	0.005	0.035	0.004	0.015	0.054	
35	0.013	0.049	0.011	0.007	0.064	0.096
36	0.005	0.038	0.005	0.018	0.051	
37	0.021	0.039	0.016	0.020	0.061	0.091
38	0.003	0.024	0.004	0.015	0.048	
39	0.009	0.018	0.006	0.024	0.058	0.087
40	0.003	0.025	0.004	0.016	0.046	

Note the higher limits for odd harmonics 21 and above are only allowable under certain conditions, if these higher limits are utilised please state the exemption used as detailed in part 6.2.3.4 of BS EN 61000-3-2 in the box below.

Model: BNT003KTL						
L2						
Micro-generator tested to BS EN 61000-3-2						
Micro-generator rating per phase (rpp)				1	kW	
For 3-phase **Micro-generator**s, tick this box if harmonic measurements are identical for all three phases. If the harmonics are not identical for each phase, please replicate this section with the results for each phase.				three phase PV inverter		
Harmonic	At 45-55% of **Registered Capacity**		100% of **Registered Capacity**			
	Measured Value MV in Amps	Normalised Value (NV) in Amps	Measured Value MV in Amps	Normalised Value (NV) in Amps	Limit in BS EN 61000-3-2 in Amps	Higher limit for odd harmonics 21 and above
2	0.018	0.132	0.025	0.090	1.080	
3	0.079	0.581	0.043	0.159	2.300	
4	0.010	0.078	0.012	0.046	0.430	
5	0.152	1.120	0.172	0.633	1.140	
6	0.010	0.071	0.009	0.032	0.300	
7	0.081	0.598	0.100	0.367	0.770	
8	0.008	0.060	0.007	0.024	0.230	
9	0.035	0.262	0.025	0.093	0.400	
10	0.010	0.069	0.008	0.030	0.184	
11	0.151	0.139	0.046	0.171	0.330	
12	0.009	0.063	0.006	0.022	0.153	
13	0.082	0.077	0.046	0.169	0.210	

14	0.007	0.049	0.007	0.026	0.131	
15	0.011	0.082	0.021	0.079	0.150	
16	0.005	0.036	0.006	0.021	0.115	
17	0.018	0.035	0.040	0.048	0.132	
18	0.005	0.039	0.006	0.023	0.102	
19	0.007	0.054	0.034	0.042	0.118	
20	0.005	0.038	0.007	0.025	0.092	
21	0.005	0.034	0.009	0.032	0.107	0.160
22	0.006	0.042	0.005	0.020	0.084	
23	0.033	0.049	0.036	0.044	0.098	0.147
24	0.005	0.040	0.006	0.023	0.077	
25	0.032	0.047	0.023	0.083	0.090	0.135
26	0.007	0.049	0.007	0.025	0.071	
27	0.006	0.040	0.008	0.031	0.083	0.124
28	0.004	0.032	0.006	0.023	0.066	
29	0.021	0.031	0.028	0.026	0.078	0.117
30	0.005	0.033	0.005	0.020	0.061	
31	0.012	0.018	0.020	0.019	0.073	0.109
32	0.004	0.032	0.005	0.020	0.058	
33	0.007	0.053	0.008	0.028	0.068	0.102
34	0.006	0.047	0.008	0.030	0.054	
35	0.018	0.034	0.018	0.022	0.064	0.096
36	0.005	0.038	0.007	0.027	0.051	
37	0.014	0.026	0.015	0.056	0.061	0.091
38	0.005	0.040	0.009	0.034	0.048	
39	0.007	0.053	0.007	0.025	0.058	0.087
40	0.006	0.042	0.007	0.024	0.046	

Note the higher limits for odd harmonics 21 and above are only allowable under certain conditions, if these higher limits are utilised please state the exemption used as detailed in part 6.2.3.4 of BS EN 61000-3-2 in the box below.

Model: BNT003KTL						
L3						
Micro-generator tested to BS EN 61000-3-2						
Micro-generator rating per phase (rpp)				1	kW	
For 3-phase **Micro-generator**s, tick this box if harmonic measurements are identical for all three phases. If the harmonics are not identical for each phase, please replicate this section with the results for each phase.				three phase PV inverter		
Harmonic	At 45-55% of **Registered Capacity**		100% of **Registered Capacity**			
	Measured Value MV in Amps	Normalised Value (NV) in Amps	Measured Value MV in Amps	Normalised Value (NV) in Amps	Limit in BS EN 61000-3-2 in Amps	Higher limit for odd harmonics 21 and above
2	0.016	0.121	0.031	0.113	1.080	
3	0.035	0.258	0.033	0.121	2.300	
4	0.011	0.078	0.013	0.047	0.430	
5	0.082	0.595	0.102	0.376	1.140	
6	0.009	0.066	0.010	0.038	0.300	
7	0.042	0.310	0.063	0.229	0.770	
8	0.009	0.067	0.006	0.023	0.230	
9	0.018	0.130	0.024	0.090	0.400	
10	0.009	0.066	0.007	0.024	0.184	
11	0.130	0.121	0.041	0.149	0.330	
12	0.009	0.064	0.006	0.021	0.153	
13	0.084	0.105	0.033	0.123	0.210	
14	0.006	0.046	0.006	0.021	0.131	
15	0.022	0.054	0.018	0.067	0.150	
16	0.006	0.043	0.006	0.021	0.115	
17	0.020	0.048	0.028	0.101	0.132	
18	0.006	0.046	0.005	0.019	0.102	
19	0.005	0.035	0.037	0.027	0.118	
20	0.005	0.040	0.005	0.020	0.092	
21	0.009	0.068	0.007	0.027	0.107	0.160
22	0.007	0.049	0.006	0.023	0.084	
23	0.025	0.038	0.028	0.021	0.098	0.147
24	0.005	0.040	0.005	0.020	0.077	
25	0.045	0.034	0.027	0.020	0.090	0.135
26	0.007	0.053	0.006	0.022	0.071	
27	0.005	0.037	0.005	0.020	0.083	0.124
28	0.005	0.035	0.007	0.027	0.066	
29	0.021	0.030	0.019	0.068	0.078	0.117
30	0.004	0.031	0.006	0.021	0.061	

31	0.011	0.029	0.028	0.021	0.073	0.109
32	0.005	0.036	0.006	0.020	0.058	
33	0.005	0.040	0.005	0.018	0.068	0.102
34	0.007	0.052	0.008	0.028	0.054	
35	0.009	0.035	0.014	0.053	0.064	0.096
36	0.005	0.038	0.006	0.021	0.051	
37	0.021	0.040	0.019	0.037	0.061	0.091
38	0.006	0.040	0.010	0.036	0.048	
39	0.004	0.031	0.005	0.018	0.058	0.087
40	0.005	0.036	0.005	0.019	0.046	

Note the higher limits for odd harmonics 21 and above are only allowable under certain conditions, if these higher limits are utilised please state the exemption used as detailed in part 6.2.3.4 of BS EN 61000-3-2 in the box below.

Model: BNT010KTL						
L1						
Micro-generator tested to BS EN 61000-3-2						
Micro-generator rating per phase (rpp)				3.33	kW	
For 3-phase **Micro-generator**s, tick this box if harmonic measurements are identical for all three phases. If the harmonics are not identical for each phase, please replicate this section with the results for each phase.				three phase PV inverter		
Harmonic	At 45-55% of **Registered Capacity**		100% of **Registered Capacity**			
	Measured Value MV in Amps	Normalised Value (NV) in Amps	Measured Value MV in Amps	Normalised Value (NV) in Amps	Limit in BS EN 61000-3-2 in Amps	Higher limit for odd harmonics 21 and above
2	0.045	0.099	0.096	0.106	1.080	
3	0.036	0.079	0.024	0.026	2.300	
4	0.013	0.029	0.013	0.014	0.430	
5	0.096	0.212	0.091	0.100	1.140	
6	0.008	0.018	0.009	0.010	0.300	
7	0.073	0.161	0.059	0.065	0.770	
8	0.007	0.015	0.007	0.008	0.230	
9	0.019	0.042	0.014	0.015	0.400	
10	0.007	0.015	0.006	0.007	0.184	
11	0.091	0.201	0.078	0.086	0.330	
12	0.005	0.011	0.005	0.006	0.153	
13	0.070	0.155	0.075	0.083	0.210	
14	0.006	0.013	0.004	0.004	0.131	
15	0.015	0.033	0.010	0.011	0.150	
16	0.007	0.015	0.006	0.007	0.115	
17	0.047	0.104	0.053	0.059	0.132	

18	0.004	0.009	0.005	0.006	0.102	
19	0.040	0.088	0.056	0.062	0.118	
20	0.005	0.011	0.006	0.007	0.092	
21	0.009	0.020	0.008	0.009	0.107	0.160
22	0.005	0.011	0.004	0.004	0.084	
23	0.018	0.040	0.026	0.029	0.098	0.147
24	0.005	0.011	0.004	0.004	0.077	
25	0.012	0.026	0.041	0.045	0.090	0.135
26	0.004	0.009	0.007	0.008	0.071	
27	0.004	0.009	0.010	0.011	0.083	0.124
28	0.004	0.009	0.004	0.004	0.066	
29	0.014	0.031	0.016	0.018	0.078	0.117
30	0.007	0.015	0.005	0.006	0.061	
31	0.015	0.033	0.027	0.030	0.073	0.109
32	0.004	0.009	0.007	0.008	0.058	
33	0.006	0.013	0.012	0.013	0.068	0.102
34	0.004	0.009	0.006	0.007	0.054	
35	0.009	0.020	0.020	0.022	0.064	0.096
36	0.004	0.009	0.006	0.007	0.051	
37	0.017	0.038	0.020	0.022	0.061	0.091
38	0.004	0.009	0.006	0.007	0.048	
39	0.006	0.013	0.013	0.014	0.058	0.087
40	0.003	0.007	0.006	0.007	0.046	

Note the higher limits for odd harmonics 21 and above are only allowable under certain conditions, if these higher limits are utilised please state the exemption used as detailed in part 6.2.3.4 of BS EN 61000-3-2 in the box below.

Model: BNT010KTL						
L2						
Micro-generator tested to BS EN 61000-3-2						
Micro-generator rating per phase (rpp)				3.33	kW	
For 3-phase **Micro-generator**s, tick this box if harmonic measurements are identical for all three phases. If the harmonics are not identical for each phase, please replicate this section with the results for each phase.				three phase PV inverter		
Harmonic	At 45-55% of **Registered Capacity**		100% of **Registered Capacity**			
	Measured Value MV in Amps	Normalised Value (NV) in Amps	Measured Value MV in Amps	Normalised Value (NV) in Amps	Limit in BS EN 61000-3-2 in Amps	Higher limit for odd harmonics 21 and above
2	0.036	0.079	0.091	0.100	1.080	
3	0.068	0.150	0.028	0.031	2.300	
4	0.011	0.024	0.013	0.014	0.430	
5	0.123	0.272	0.126	0.139	1.140	
6	0.009	0.020	0.029	0.032	0.300	
7	0.111	0.245	0.112	0.124	0.770	
8	0.007	0.015	0.008	0.009	0.230	
9	0.021	0.046	0.008	0.009	0.400	
10	0.007	0.015	0.008	0.009	0.184	
11	0.096	0.212	0.085	0.094	0.330	
12	0.009	0.020	0.016	0.018	0.153	
13	0.075	0.166	0.067	0.074	0.210	
14	0.006	0.013	0.006	0.007	0.131	
15	0.014	0.031	0.013	0.014	0.150	
16	0.007	0.015	0.006	0.007	0.115	
17	0.052	0.115	0.055	0.061	0.132	
18	0.007	0.015	0.010	0.011	0.102	
19	0.040	0.088	0.059	0.065	0.118	
20	0.005	0.011	0.008	0.009	0.092	
21	0.006	0.013	0.011	0.012	0.107	0.160
22	0.006	0.013	0.005	0.006	0.084	
23	0.024	0.053	0.026	0.029	0.098	0.147
24	0.005	0.011	0.006	0.007	0.077	
25	0.019	0.042	0.041	0.045	0.090	0.135
26	0.006	0.013	0.012	0.013	0.071	

27	0.005	0.011	0.009	0.010	0.083	0.124
28	0.004	0.009	0.005	0.006	0.066	
29	0.012	0.026	0.018	0.020	0.078	0.117
30	0.006	0.013	0.006	0.007	0.061	
31	0.012	0.026	0.028	0.031	0.073	0.109
32	0.005	0.011	0.009	0.010	0.058	
33	0.005	0.011	0.008	0.009	0.068	0.102
34	0.006	0.013	0.008	0.009	0.054	
35	0.014	0.031	0.018	0.020	0.064	0.096
36	0.005	0.011	0.006	0.007	0.051	
37	0.010	0.022	0.021	0.023	0.061	0.091
38	0.006	0.013	0.007	0.008	0.048	
39	0.006	0.013	0.010	0.011	0.058	0.087
40	0.005	0.011	0.006	0.007	0.046	

Note the higher limits for odd harmonics 21 and above are only allowable under certain conditions, if these higher limits are utilised please state the exemption used as detailed in part 6.2.3.4 of BS EN 61000-3-2 in the box below.

Model: BNT010KTL						
L3						
Micro-generator tested to BS EN 61000-3-2						
Micro-generator rating per phase (rpp)				3.33	kW	
For 3-phase **Micro-generator**s, tick this box if harmonic measurements are identical for all three phases. If the harmonics are not identical for each phase, please replicate this section with the results for each phase.				three phase PV inverter		
Harmonic	At 45-55% of **Registered Capacity**		100% of **Registered Capacity**			
	Measured Value MV in Amps	Normalised Value (NV) in Amps	Measured Value MV in Amps	Normalised Value (NV) in Amps	Limit in BS EN 61000-3-2 in Amps	Higher limit for odd harmonics 21 and above
2	0.051	0.113	0.056	0.062	1.080	
3	0.052	0.115	0.034	0.038	2.300	
4	0.011	0.024	0.010	0.011	0.430	
5	0.082	0.181	0.091	0.100	1.140	
6	0.008	0.018	0.025	0.028	0.300	
7	0.058	0.128	0.064	0.071	0.770	
8	0.008	0.018	0.007	0.008	0.230	
9	0.012	0.026	0.011	0.012	0.400	
10	0.007	0.015	0.006	0.007	0.184	
11	0.073	0.161	0.071	0.078	0.330	
12	0.008	0.018	0.014	0.015	0.153	

13	0.077	0.170	0.060	0.066	0.210	
14	0.005	0.011	0.007	0.008	0.131	
15	0.020	0.044	0.018	0.020	0.150	
16	0.009	0.020	0.007	0.008	0.115	
17	0.032	0.071	0.051	0.056	0.132	
18	0.005	0.011	0.007	0.008	0.102	
19	0.051	0.113	0.056	0.062	0.118	
20	0.004	0.009	0.005	0.006	0.092	
21	0.008	0.018	0.009	0.010	0.107	0.160
22	0.004	0.009	0.005	0.006	0.084	
23	0.019	0.042	0.017	0.019	0.098	0.147
24	0.005	0.011	0.008	0.009	0.077	
25	0.018	0.040	0.037	0.041	0.090	0.135
26	0.006	0.013	0.005	0.006	0.071	
27	0.004	0.009	0.009	0.010	0.083	0.124
28	0.004	0.009	0.006	0.007	0.066	
29	0.009	0.020	0.011	0.012	0.078	0.117
30	0.005	0.011	0.008	0.009	0.061	
31	0.012	0.026	0.035	0.039	0.073	0.109
32	0.004	0.009	0.004	0.004	0.058	
33	0.005	0.011	0.008	0.009	0.068	0.102
34	0.008	0.018	0.007	0.008	0.054	
35	0.010	0.022	0.019	0.021	0.064	0.096
36	0.006	0.013	0.006	0.007	0.051	
37	0.016	0.035	0.026	0.029	0.061	0.091
38	0.007	0.015	0.007	0.008	0.048	
39	0.005	0.011	0.006	0.007	0.058	0.087
40	0.005	0.011	0.006	0.007	0.046	

Note the higher limits for odd harmonics 21 and above are only allowable under certain conditions, if these higher limits are utilised please state the exemption used as detailed in part 6.2.3.4 of BS EN 61000-3-2 in the box below.

3. Power Quality – Voltage fluctuations and Flicker:	P

These tests should be undertaken in accordance with EREC G98 Annex A1 A.1.3.3 (**Inverter** connected) or Annex A2 A.2.3.3 (Synchronous).

The standard test impedance is 0.4 Ω for a single phase **Micro-generating Plant** (and for a two phase unit in a three phase system) and 0.24 Ω for a three phase **Micro-generating Plant** (and for a two phase unit in a split phase system). Please ensure that both test and standard impedance are completed on this form. If the test impedance (or the measured impedance) is different to the standard impedance, it must be normalised to the standard impedance as follows (where the **Power Factor** of the generation output is 0.98 or above):

d max normalised value = (Standard impedance / Measured impedance) x Measured value.

Where the **Power Factor** of the output is under 0.98 then the X to R ratio of the test impedance should be close to that of the standard impedance.

The stopping test should be a trip from full load operation.

The duration of these tests needs to comply with the particular requirements set out in the testing notes for the technology under test.

The test date and location must be declared.

Test start date	2022-07-06	Test end date	2022-07-06
Test location	No.99, Hongye Road, Suzhou Industrial Park, Suzhou, Jiangsu, P.R. China		

Model:	BNT010KTL

L1

	Starting			Stopping			Running	
	d(max)	d(c)	d(t)	d(max)	d(c)	d(t)	P_{st}	P_{lt} 2 hours
Measured Values at test impedance	0.20	0.04	0	0.20	0.05	0	0.14	0.11
Normalised to standard impedance	0.20	0.04	0	0.20	0.05	0	0.14	0.11
Normalised to required maximum impedance	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Limits set under BS EN 61000-3-11	4%	3.3%	3.3%	4%	3.3%	3.3%	1.0	0.65

Test Impedance	R	0.24	Ω	Xl	0.15	Ω
Standard Impedance	R	0.24 * 0.4 ^	Ω	Xl	0.15 * 0.25 ^	Ω
Maximum Impedance	R	N/A #	Ω	Xl	N/A #	Ω

*Applies to three phase and split single phase **Micro-generators**. Delete as appropriate.

^ Applies to single phase **Micro-generators** and **Micro-generators** using two phases on a three phase system. Delete as appropriate.

Model:	BNT010KTL

L2								
	Starting			Stopping			Running	
	d(max)	d(c)	d(t)	d(max)	d(c)	d(t)	P_{st}	P_{lt} 2 hours
Measured Values at test impedance	0.26	0.06	0	0.28	0.06	0	0.12	0.10
Normalised to standard impedance	0.26	0.06	0	0.28	0.06	0	0.12	0.10
Normalised to required maximum impedance	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Limits set under BS EN 61000-3-11	4%	3.3%	3.3%	4%	3.3%	3.3%	1.0	0.65

Test Impedance	R	0.24	Ω	Xl	0.15	Ω
Standard Impedance	R	0.24 * 0.4 ^	Ω	Xl	0.15 * 0.25 ^	Ω
Maximum Impedance	R	N/A #	Ω	Xl	N/A #	Ω

*Applies to three phase and split single phase **Micro-generators**. Delete as appropriate.

^ Applies to single phase **Micro-generators** and **Micro-generators** using two phases on a three phase system. Delete as appropriate.

Model:	BNT010KTL

L3								
	Starting			Stopping			Running	
	d(max)	d(c)	d(t)	d(max)	d(c)	d(t)	P_{st}	P_{lt} 2 hours
Measured Values at test impedance	0.26	0.06	0	0.28	0.06	0	0.12	0.10
Normalised to standard impedance	0.26	0.06	0	0.28	0.06	0	0.12	0.10
Normalised to required maximum impedance	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Limits set under BS EN 61000-3-11	4%	3.3%	3.3%	4%	3.3%	3.3%	1.0	0.65

Test Impedance	R	0.24	Ω	Xl	0.15	Ω

Standard Impedance	R	0.24 * 0.4 ^	Ω	Xl	0.15 * 0.25 ^	Ω
Maximum Impedance	R	N/A #	Ω	Xl	N/A #	Ω

*Applies to three phase and split single phase **Micro-generators**. Delete as appropriate.

^ Applies to single phase **Micro-generators** and **Micro-generators** using two phases on a three phase system. Delete as appropriate.

4. Power quality – DC injection:	**P**

This test should be carried out in accordance with A 1.3.4 as applicable.
The % **DC** injection ("as % of rated AC current" below) is calculated as follows:
% **DC** injection = Recorded **DC** value in Amps / base current
where the base current is the **Registered Capacity** (W) / 230 V. The % **DC** injection should not be greater than 0.25%.

Model: BNT003KTL				
L1				
Test power level	20%	50%	75%	100%
Recorded DC injection value in Amps	-0.010	-0.010	-0.005	-0.007
as % of rated AC current	-0.08%	-0.08%	-0.04%	-0.05%
Limit	0.25%	0.25%	0.25%	0.25%
Model: BNT003KTL				
L2				
Test power level	20%	50%	75%	100%
Recorded DC injection value in Amps	-0.011	-0.008	-0.006	-0.006
as % of rated AC current	-0.08%	-0.06%	-0.05%	-0.05%
Limit	0.25%	0.25%	0.25%	0.25%
Model: BNT003KTL				
L3				
Test power level	20%	50%	75%	100%
Recorded DC injection value in Amps	-0.009	-0.009	-0.005	-0.006
as % of rated AC current	-0.07%	-0.07%	-0.04%	-0.05%
Limit	0.25%	0.25%	0.25%	0.25%

Model: BNT010KTL				
L1				
Test power level	20%	50%	75%	100%
Recorded DC injection value in Amps	-0.027	-0.028	-0.028	-0.026
as % of rated AC current	-0.06%	-0.06%	-0.06%	-0.06%
Limit	0.25%	0.25%	0.25%	0.25%
Model: BNT010KTL				

L2				
Test power level	20%	50%	75%	100%
Recorded DC injection value in Amps	-0.033	-0.033	-0.033	-0.034
as % of rated AC current	-0.08%	-0.08%	-0.08%	-0.08%
Limit	0.25%	0.25%	0.25%	0.25%
Model: BNT010KTL				
L3				
Test power level	20%	50%	75%	100%
Recorded DC injection value in Amps	-0.023	-0.027	-0.024	-0.028
as % of rated AC current	-0.05%	-0.06%	-0.06%	-0.06%
Limit	0.25%	0.25%	0.25%	0.25%

5. Power Factor:			**P**
This test shall be carried out in accordance with A.1.3.2 and A.2.3.2 at three voltage levels and at **Registered Capacity** and the measured **Power Factor** must be greater than 0.95 to pass. Voltage to be maintained within ±1.5% of the stated level during the test.			
Model: BNT010KTL			
Voltage	0.94 pu (216.2 V)	1 pu (230 V)	1.1 pu (253 V)
Measured value	0.9999	0.9999	0.9999
Power Factor Limit	>0.95	>0.95	>0.95
Model: BNT003KTL			
Voltage	0.94 pu (216.2 V)	1 pu (230 V)	1.1 pu (253 V)
Measured value	0.9990	09990	0.9990
Power Factor Limit	>0.95	>0.95	>0.95

6. Protection – Frequency tests:						**P**
These tests should be carried out in accordance with Annex A1 A.1.2.3 (**Inverter** connected) or Annex A2 A.2.2.3 (Synchronous). For trip tests, frequency and time delay should be stated. For “no trip tests”, “no trip” can be stated.						
Model: BNT010KTL						
Function	Setting		Trip test		“No trip tests”	
	Frequency	Time delay	Frequency	Time delay	Frequency / time	Confirm no trip
U/F stage 1	47.5 Hz	20 s	47.5	20.03s	47.7 Hz 30 s	No trip
U/F stage 2	47.0 Hz	0.5 s	46.99	0.562s	47.2 Hz 19.5 s	No trip
					46.8 Hz 0.45 s	No trip
O/F	52.0 Hz	0.5 s	52.01	0.557s	51.8 Hz 120.0 s	No trip

					52.2 Hz 0.45 s	No trip
Note: For frequency trip tests the frequency required to trip is the setting ± 0.1 Hz. In order to measure the time delay a larger deviation than the minimum required to operate the projection can be used. The “No trip tests” need to be carried out at the setting ± 0.2 Hz and for the relevant times as shown in the table above to ensure that the protection will not trip in error.						

7. Protection – Voltage tests:						**P**
These tests should be carried out in accordance with Annex A1 A.1.2.2 (**Inverter** connected) or Annex A2 A.2.2.2 (Synchronous). For trip tests, voltage and time delay should be stated. For “no trip tests”, “no trip” can be stated.						
Model: BNT010KTL						
L1						
Function	Setting		Trip test		“No trip tests”	
	Voltage	Time delay	Voltage	Time delay	Voltage / time	Confirm no trip
U/V	0.8 pu (184 V)	2.5 s	183.5	2.562	188 V 5.0 s	No trip
					180 V 2.45 s	No trip
O/V stage 1	1.14 pu (262.2 V)	1.0 s	262.8	1.025	258.2 V 5.0 s	No trip
O/V stage 2	1.19 pu (273.7 V)	0.5 s	273.6	0.561	269.7 V 0.95 s	No trip
					277.7 V 0.45 s	No trip

Model: BNT010KTL						
L2						
Function	Setting		Trip test		“No trip tests”	
	Voltage	Time delay	Voltage	Time delay	Voltage / time	Confirm no trip
U/V	0.8 pu (184 V)	2.5 s	183.6	2.552	188 V 5.0 s	No trip
					180 V 2.45 s	No trip
O/V stage 1	1.14 pu (262.2 V)	1.0 s	263.1	1.042	258.2 V 5.0 s	No trip
O/V stage 2	1.19 pu (273.7 V)	0.5 s	274.3	0.534	269.7 V 0.95 s	No trip
					277.7 V 0.45 s	No trip

Model: BNT010KTL						
L3						
Function	Setting		Trip test		“No trip tests”	
	Voltage	Time delay	Voltage	Time delay	Voltage / time	Confirm no trip
U/V	0.8 pu	2.5 s	182.4	2.545	188 V	No trip

	(184 V)				5.0 s	
					180 V 2.45 s	No trip
O/V stage 1	1.14 pu (262.2 V)	1.0 s	263.8	1.038	258.2 V 5.0 s	No trip
O/V stage 2	1.19 pu (273.7 V)	0.5 s	275.0	0.546	269.7 V 0.95 s	No trip
					277.7 V 0.45 s	No trip
Note: For Voltage tests the Voltage required to trip is the setting ±3.45 V. The time delay can be measured at a larger deviation than the minimum required to operate the protection. The No trip tests need to be carried out at the setting ±4 V and for the relevant times as shown in the table above to ensure that the protection will not trip in error.						

8. Protection – Loss of Mains test:						**P**
For PV **Inverter**s shall be tested in accordance with BS EN 62116. Other **Micro-generator**s should be tested in accordance with A.2.2.4 at 10%, 55% and 100% of rated power. For test condition A, EUT output = 100 % P_n, test condition B, EUT output = 50 % to 66 % P_n, and test condition C, EUT output = 25 % to 33 % P_n.						
Model: BNT010KTL						
For **Inverter**s tested to BS EN 62116 the following sub set of tests should be recorded in the following table.						
Test Power and imbalance	33% -5% Q Test 22	66% -5% Q Test 12	100% -5% P Test 5	33% +5% Q Test 31	66% +5% Q Test 21	100% +5% P Test 10
Trip time. **Limit is 0.5s**	0.171s	0.176s	0.184s	0.174s	0.176s	0.178s

8. Protection – Frequency change, Vector Shift Stability test:			**P**
This test should be carried out in accordance with EREC G98 Annex A1 A.1.2.6 (**Inverter** connected) or Annex A2 A.2.2.6 (Synchronous). Confirmation is required that the **Micro-generating Plant** does not trip under positive / negative vector shift.			
Model: BNT010KTL			
	Start Frequency	Change	Confirm no trip
Positive Vector Shift	49.0 Hz	+50 degrees	No trip
Negative Vector Shift	50.0 Hz	-50 degrees	No trip

8. Protection – Frequency change, RoCoF Stability test:			**P**
The requirement is specified in section 11.3, test procedure in Annex A.1.2.6 (**Inverter** connected) or Annex A2 A.2.2.6 (Synchronous). Confirmation is required that the **Micro-generating Plant** does not trip for the duration of the ramp up and ramp down test.			
Model: BNT010KTL			
Ramp range	Test frequency ramp:	Test Duration	Confirm no trip
49.0 Hz to 51.0 Hz	+0.95 Hzs^{-1}	2.1 s	No trip
51.0 Hz to 49.0 Hz	-0.95 Hzs^{-1}	2.1 s	No trip

9. Limited Frequency Sensitive Mode – Over frequency test:					**P**
This test should be carried out in accordance with A.1.2.9. The test should be carried out using the specific threshold frequency of 50.4 Hz and **Droop** of 10%. The measurement tolerances are contained in A.1.2.9.					
Model: BNT010KTL					
Alternatively, simulation results should be noted below:					
Test sequence at **Registered Capacity** >80%	Measured **Active Power** Output (W)	Frequency (Hz)	Calculated droop (%)	Primary Power Source	**Active Power** Gradient
Step a) 50.00 Hz ±0.01 Hz	10000.61	50.00	-	Photovoltaic array simulator	-
Step b) 50.45 Hz ±0.05 Hz	9895.17	50.45	9.49		-
Step c) 50.70 Hz ±0.10 Hz	9357.79	50.70	9.34		-
Step d) 51.15 Hz ±0.05 Hz	8434.82	51.15	9.58		-
Step e) 50.70 Hz ±0.10 Hz	9369.30	50.70	9.50		-
Step f) 50.45 Hz ±0.05 Hz	9895.53	50.45	9.53		-
Step g) 50.00 Hz ±0.01 Hz	10000.36	50.00	-		
Test sequence at **Registered Capacity** 40-60%	Measured **Active Power** Output (W)	Frequency (Hz)	Calculated droop (%)	Primary Power Source	**Active Power** Gradient
Step a) 50.00 Hz ±0.01 Hz	5001.77	50.00	-	Photovoltaic array simulator	-
Step b) 50.45 Hz ±0.05 Hz	4899.31	50.45	9.73		-
Step c) 50.70 Hz ±0.10 Hz	4367.48	50.70	9.46		-
Step d) 51.15 Hz ±0.05 Hz	3420.22	51.15	9.48		-
Step e) 50.70 Hz ±0.10 Hz	4365.84	50.70	9.43		-
Step f) 50.45 Hz ±0.05 Hz	4894.91	50.45	9.30		-
Step g) 50.00 Hz ±0.01 Hz	5001.07	50.00	-		
The frequency at each step should be maintained for at least one minute and the Active Power reduction in the form of a gradient determined and assessed for compliance with paragraph 11.2.3. The Droop should be determined from the measurements between 50.4 Hz and 51.15 Hz. The allowed tolerance for the frequency measurement shall be ± 0.05 Hz. The allowed tolerance for Active Power output measurement shall be ±10% of the required change in Active Power. The resulting overall tolerance range for a nominal 10% Droop is +2.8% and – 1.5%, ie a Droop less than 12.8% and greater than 8.5%.					

10. Power output with falling frequency test (For PV Inverter):			**P**
This test should be carried out in accordance with A.1.2.7.			
Model: BNT010KTL			
Test sequence	Measured **Active Power** Output (W)	Frequency (Hz)	Primary power source
Test a) 50 Hz ± 0.01 Hz	10030.59	50.00	Photovoltaic array simulator
Test b) Point between 49.5 Hz and 49.6 Hz	10029.18	49.55	Photovoltaic array simulator
Test c) Point between 47.5 Hz and 47.6 Hz	10026.53	47.55	Photovoltaic array simulator

NOTE:
The operating point in Test (b) and (c) shall be maintained for at least 5 minutes

The test is regarded as passed if:
• the Micro-generator does not disconnect from the network at the operating points a) to c) when the network frequency is changed and
• the Micro-generator does not reduce output energy at point b) and
• the power reduction at point c) is less than or equal to the allowed power reduction according to paragraph 9.4.2 (Figure 3).

The following data shall be documented:
• variation of the network frequency with time;
• the measured Active Power with time.

12. Re-connection timer					**P**
Model: BNT010KTL					
Test should prove that the reconnection sequence starts after a minimum delay of 20 s for restoration of voltage and frequency to within the stage 1 settings of Table 2. Both the time delay setting and the measured delay should be provided in this form; both should be greater than 20 s to pass. Confirmation should be provided that the **Micro-generating Plant** does not reconnect at the voltage and frequency settings below; a statement of “no reconnection” can be made.					
Time delay setting	Measured delay	Checks on no reconnection when voltage or frequency is brought to just outside stage 1 limits of Table 10.1.			
60s	60.4s	At 1.16 pu (266.2 V)	At 0.78 pu (180.0 V)	At 47.4 Hz	At 52.1 Hz
Confirmation that the **Micro-generator** does not re-connect.		No Reconnection	No Reconnection	No Reconnection	No Reconnection
Recover to normal operation range after confirmation of no connection		Yes	Yes	Yes	Yes
Confirmation that the Power Generating Module shall reconnect		Reconnection after 61.0 s	Reconnection after 61.1 s	Reconnection after 60.4 s	Reconnection after 61.1 s

13. Fault level contribution:					**P**
These tests shall be carried out in accordance with EREC G98 Annex A1 A.1.3.5 (**Inverter** connected) and Annex A2 A.2.3.4 (Synchronous). Please complete each entry, even if the fault contribution is zero.					
Model: BNT010KTL					
For machines with electro-magnetic output			For **Inverter** output		
Parameter	Symbol	Value	Time after fault	Volts	Amps
Peak Short Circuit current	i_p	N/A	20ms	17.41V	18.78A
Initial Value of aperiodic current	A	N/A	100ms	17.57V	16.72A
Initial symmetrical short-circuit current*	I_k	N/A	250ms	0	0
Decaying (aperiodic) component of short circuit current*	i_{DC}	N/A	500ms	0	0
Reactance/Resistance Ratio of source*	$^X/_R$	N/A	Time to trip	165.6ms	In seconds
For rotating machines and linear piston machines the test should produce a 0 s – 2 s plot of the short circuit current as seen at the **Micro-generator** terminals. * Values for these parameters should be provided where the short circuit duration is sufficiently long to enable interpolation of the plot.					

14. Logic interface (input port)	
Confirm that an input port is provided and can be used to reduce the **Active Power** output to zero	**Yes**
Provide high level description of logic interface, e.g. details in 9.4.3 such as AC or **DC** signal (the additional comments box below can be used)	**Yes**
15. Self-Monitoring solid state switching: No specified test requirements. **Refer to EREC G98 Annex A1 A.1.3.6 (Inverter connected).**	
It has been verified that in the event of the solid state switching device failing to disconnect the **Micro-generator**, the voltage on the output side of the switching device is reduced to a value below 50 V within 0.5 s.	**N/A**
16. Cyber security	
Confirm that the **Manufacturer** or **Installer** of the **Micro-generator** has provided a statement describing how the **Micro-generator** has been designed to comply with cyber security requirements, as detailed in 9.7.	Yes，Manufacturer's declaration provided.
Additional comments.	
To short or open pin1 and pin5 of logic interface port (RS485 port) to control the inverter to normal or shutdown active power of output. A logic interface is provided that can be operated by an external switch or contactor. Users can install by themselves. Users install the switch connected to pin1 and pin5 of RS485 port and just need control the switch signal causing the switch to open or short. When the switch is closed, the inverter will operate normally. When the switch is opened, the inverter will cease to export active power within 5 seconds. The signal from the inverter that is being switched is DC (maximum value 3.3V).	